

# MAZDA 323/PROTEGE 1990-94

REAR BUMPER Cont'd		
WAGON Cont'd		
1 Center		BJ19-50-221
2 Outer	R	BJ19-50-231
	L	BJ19-50-241
3 Moulding, Cover		
Bright		BJ20-50-225
Argent		BJ19-50-225
4 Brkt, Slide Outer	R/L	B092-50-230
5 Brkt, Slide Inner	R	BJ19-50-232
	L	BJ19-50-242
6 Plate, Stud Outer	R	BJ19-50-234
	L	BJ19-50-244
7 Plate, Stud Inner	R	BJ19-50-2A1
	L	BJ19-50-2B1
8 Absorber, Impact	R	BJ19-50-223
	L	BJ19-50-224
9 Retainer, Cover		BJ19-50-229
10 Bar Assy, Reinforcement Retainer to Reinforcement		BJ19-50-260
11 Upper		BJ19-50-1Z0
12 Lower		BJ19-50-0D0
		<i>Included w/Reinforcement Bar Assy</i>
13 Arm, Bumper Mounting	R	BJ19-50-270
	L	BJ19-50-280

## MAZDA 323/PROTEGE 1990-94

SECTION INDEX	
A/C /HEATER/VENTILATION .....	46
A/C REFRIGERANT CAPACITIES .....	46
AIR CLEANER .....	50
BACK WINDOW .....	55
CENTER CONSOLE .....	51
CLEAR COAT IDENTIFICATION .....	44
COOLING .....	46
COWL & DASH .....	51
CRUISE CONTROL SYSTEM .....	47
ELECTRICAL .....	50
EMISSION SYSTEM .....	50
ENGINE .....	49
ENGINE MOUNTS .....	50
EXHAUST .....	50
FRONT BUMPER .....	44
FRONT DOOR .....	53
FRONT DRIVE AXLE .....	48
FRONT FENDER .....	46
FRONT INNER STRUCTURE .....	47
FRONT LAMPS .....	45
FRONT STEERING LINKAGE/GEAR .....	49
FRONT SUSPENSION .....	48
FUEL TANK .....	59
GRILLE .....	45
HOOD .....	45
INFORMATION LABELS .....	44
INSTRUMENT PANEL .....	51
LIFTGATE .....	57
LUGGAGE LID .....	57
PAINT CODE LOCATION .....	44
QUARTER GLASS .....	57
QUARTER PANEL .....	56
REAR BODY .....	59
REAR BUMPER .....	61
REAR DOOR .....	54
REAR DRIVE AXLE .....	59
REAR LAMPS .....	59
REAR SEAT .....	52
REAR SUSPENSION .....	58
ROCKER/PILLARS/FLOOR .....	51
ROOF .....	55
SEAT .....	52
SEAT BELTS .....	52
STEERING PUMP .....	49
STEERING WHEEL/COLUMN .....	49
SUNROOF .....	55
UNDERHOOD DIMENSIONS .....	47
WHEEL .....	47
WINDSHIELD .....	50

### PAINT CODE LOCATION

Paint code located on left lock pillar or engine compartment.

### CLEAR COAT IDENTIFICATION


All metallic colors are clear coat.

### INFORMATION LABELS

1 Label, Logo	B6S7-13-309
2 Label, Radiator Caution	8791-15-201
Label, A/C Caution	UE38-61-439
3 Label, Caution	
USA	
1.6L Eng	E301-15-031

1.8L Eng	E301-15-031
Man Trans	B660-15-031
Auto Trans	N.A.
Canada	
4 Caution Plate	E563-15-201
1.6L Eng	
1.8L Eng	
Man Trans	E563-15-201
Auto Trans	0488-15-201
5 Model Plate	8595-69-011B
6 Label, Battery	FA03-69-C72A
7 Label, Caution	FA01-69-064B
8 Label, Oil	
SOHC Eng	BR93-69-D21D
DOHC Eng	BR86-69-D21E
Label, Emission	BB7A-69-036
<i>(Order by Application)</i>	
Label, Vehicle Information	B001-69-D51
Label, Vacuum Diaphragm	
1.6L Eng	
1990-92	BR78-69-044
1993	
w/Calif Emission	BR97-69-044
w/o Calif Emission	BR78-69-044
1994	BR97-69-044
1.8L Eng	
SOHC Eng	BB7L-69-044
DOHC Eng	BB7E-69-044
9 Caution Plate	GA02-69-068
10 Tire Plate	
FWD	
1.6L Eng	BR86-69-014A
1.8L Eng	
SOHC Eng	BR87-69-014A
DOHC Eng	BW1N-69-014A
AWD	BA1C-69-014A
11 Label, Child Proof-English	R/L BA06-72-301
Label, Fuel Warning	KA10-69-D61A
12 Label, Unleaded Fuel	UB40-69-C61
Label, Fuel Economy	UB40-69-C61
13 Label, Temporary Tire	
FWD	
USA	BF68-69-073B
Canada	
English	N.A.
French	N.A.
AWD	BK14-69-073
14 Label, Tire Caution	BR70-61-438
Safety Panel	
Canada	N.A.
Label, Indicator-See Steering Wheel/Column Section	

### FRONT BUMPER




1 Cover, Front	
Black	BR70-50-031
Painted (P)	BR71-50-031A
(P) Paint to Match	
2 Tape, Stripe	R BA1C-50-0D5
	L BA1C-50-0D6
3 Bracket, Lower	R/L BR70-50-G21-2
4 Fastener (10)	BF67-50-235
5 Absorber, Impact	R/L BR70-50-111-2
6 Bar, Reinforcement Retainer, Cover	BR70-50-070
7 Side	R BR70-50-1Z2
	L BR70-50-1Z3
8 Center Rivet (7)	BR70-50-1Z1
Frame, License Plate	
9 Upper	GJ21-50-183
10 Lower	
FWD	GJ21-50-180
AWD	BA1E-50-180
11 Bracket, License Plate Spoiler, Air	H005-50-060
	BA1E-51-9L0

# MAZDA 323/PROTEGE 1990-94

## GRILLE

### HATCHBACK 1990-92




035-01249

- 1 Grille Assy (P) BRY3-50-710  
(P) Paint to Match
- 2 Nameplate (a) B300-51-771  
"Mazda"
- 3 Clip, Grille Side (a) R/L B092-50-715  
(2/Side)
- 4 Clip, Grille Center (a) 9991-00-410  
(a) Included w/Grille Assy
- 5 Moulding, Below Lamp R B455-50-7J1-5D  
L B455-50-7K1-5D

†Harbor Blue listed, Order by Application  
DV Bay Blue; DX Honey Blue; FZ Herbie Green;  
GU Shade Green; PZ Brilliant Black;  
SQ Blaze Red; SS Coral Red; UF Clear White;  
IH Steel Gray MC; IS Niagara Silver MC;  
Z1 Bluish Green M; 3L Silver Stone MC;  
4C, 4Z Silent Silver; 5D Harbor Blue MC;  
5S Neat Green MC; 6C Mighty Gray;  
6L Graceful Red MC; 6M Elegant Beige;  
6N Current Blue MC; 6V Raspberry Metallic;  
6W Laguna Blue M; 6Y Sea Mist M  
E9 Deep Purple; J4 Passion Rose

Clip, Moulding R/L B092-50-782

### HATCHBACK 1993-95




035-02237

- 1 Grille Assy (P) BBYB-50-710B  
(P) Paint to Match
- 2 Emblem (a) GA8B-51-731  
BB0S-50-717
- 3 Clip, Emblem (a) (2) R/L B092-50-715  
(2/Side)
- 4 Clip, Grille Side (a) 9991-00-410  
(a) Included w/Grille Assy
- 5 Clip, Grille Center (a) R B455-50-7J1-5D  
L B455-50-7K1-5D
- 6 Moulding, Below Lamp R B455-50-7J1-5D  
L B455-50-7K1-5D

†Harbor Blue listed, Order by Application  
DV Bay Blue; DX Honey Blue; FZ Herbie Green;  
GU Shade Green; PZ Brilliant Black;  
SQ Blaze Red; SS Coral Red; UF Clear White;  
IH Steel Gray MC; IS Niagara Silver MC;  
Z1 Bluish Green M; 3L Silver Stone MC;  
4C, 4Z Silent Silver; 5D Harbor Blue MC;  
5S Neat Green MC; 6C Mighty Gray;  
6L Graceful Red MC; 6M Elegant Beige;  
6N Current Blue MC; 6V Raspberry Metallic;  
6W Laguna Blue M; 6Y Sea Mist M  
E9 Deep Purple; J4 Passion Rose

Clip, Moulding R/L B092-50-782

### SEDAN 1990-92




035-01250

- 1 Grille Assy (P) BAYC-50-710  
(P) Paint to Match
- 2 Nameplate (a) B300-51-771  
"Mazda"
- 3 Clip, Grille (a) B092-50-715  
B455-50-712
- 4 Grommet, Screw (a) (a) Included w/Grille Assy
- 5 Moulding, Below Lamp R B455-50-7J1-5D  
L B455-50-7K1-5D

†Harbor Blue listed, Order by Application  
DV Bay Blue; DX Honey Blue; FZ Herbie Green;  
GU Shade Green; PZ Brilliant Black;  
SQ Blaze Red; SS Coral Red; UF Clear White;  
IH Steel Gray MC; IS Niagara Silver MC;  
Z1 Bluish Green M; 3L Silver Stone MC;  
4C, 4Z Silent Silver; 5D Harbor Blue MC;  
5S Neat Green MC; 6C Mighty Gray;  
6L Graceful Red MC; 6M Elegant Beige;  
6N Current Blue MC; 6V Raspberry Metallic;  
6W Laguna Blue M; 6Y Sea Mist M  
E9 Deep Purple; J4 Passion Rose

Clip, Moulding R/L B092-50-782

### SEDAN 1993




035-02238

- 1 Grille Assy (P) BBYD-50-710A  
(P) Paint to Match
- 2 Emblem (a) GA8B-51-731  
BB0S-50-717
- 3 Clip, Emblem (a) (2) B092-50-715  
B455-50-712
- 4 Clip, Grille (a) (a) Included w/Grille Assy
- 5 Grommet, Screw (a) R B455-50-7J1-5D  
L B455-50-7K1-5D
- 6 Moulding, Below Lamp R B455-50-7J1-5D  
L B455-50-7K1-5D

†Harbor Blue listed, Order by Application  
DV Bay Blue; DX Honey Blue; FZ Herbie Green;  
GU Shade Green; PZ Brilliant Black;  
SQ Blaze Red; SS Coral Red; UF Clear White;  
IH Steel Gray MC; IS Niagara Silver MC;  
Z1 Bluish Green M; 3L Silver Stone MC;  
4C, 4Z Silent Silver; 5D Harbor Blue MC;  
5S Neat Green MC; 6C Mighty Gray;  
6L Graceful Red MC; 6M Elegant Beige;  
6N Current Blue MC; 6V Raspberry Metallic;  
6W Laguna Blue M; 6Y Sea Mist M  
E9 Deep Purple; J4 Passion Rose

Clip, Moulding R/L B092-50-782

### SEDAN 1994-95



035-02237

- 1 Grille Assy (P) BBYB-50-710B  
(P) Paint to Match
- 2 Emblem (a) GA8B-51-731  
BB0S-50-717
- 3 Clip, Emblem (a) (2) R/L B092-50-715  
(2/Side)
- 4 Clip, Grille Side (a) 9991-00-410  
(a) Included w/Grille Assy
- 5 Clip, Grille Center (a) R B455-50-7J1-5D  
L B455-50-7K1-5D
- 6 Moulding, Below Lamp R B455-50-7J1-5D  
L B455-50-7K1-5D

†Harbor Blue listed, Order by Application  
DV Bay Blue; DX Honey Blue; FZ Herbie Green;  
GU Shade Green; PZ Brilliant Black;  
SQ Blaze Red; SS Coral Red; UF Clear White;  
IH Steel Gray MC; IS Niagara Silver MC;  
Z1 Bluish Green M; 3L Silver Stone MC;  
4C, 4Z Silent Silver; 5D Harbor Blue MC;  
5S Neat Green MC; 6C Mighty Gray;  
6L Graceful Red MC; 6M Elegant Beige;  
6N Current Blue MC; 6V Raspberry Metallic;  
6W Laguna Blue M; 6Y Sea Mist M  
E9 Deep Purple; J4 Passion Rose


Clip, Moulding R/L B092-50-782

## FRONT LAMPS

### HEADLAMP

Illustration Located in Next Column

- 1 Headlamp Assy  
Hatchback R 8DBR-51-030B  
L 8DBR-51-040B



035-01251

- Sedan  
SOHC Eng  
To 7-1-93 R 8DBP-51-030B  
L 8DBP-51-040B  
From 7-1-93 R 8DBR-51-030B  
L 8DBR-51-040B
- DOHC Eng  
To 7-1-93 R 8DBP-51-030B  
L 8DBP-51-040B  
From 7-1-93 R 8DBR-51-030B  
L 8DBR-51-040B

- 2 Lens & Body Hatchedback R BR93-51-0K0B  
L BR93-51-0L0B  
From 5-1-93 R BR93-51-0K0B  
L BR93-51-0L0B


- Sedan  
SOHC Eng  
To 5-1-93 R BR70-51-0K0B  
L BR70-51-0L0B
- From 5-1-93 to 7-1-93  
Right BR93-51-0K0B  
Left BR70-51-0L0B
- From 7-1-93 R BR93-51-0K0B  
L BR93-51-0L0B

- DOHC Eng  
To 9-1-92 R BR70-51-0K0B  
L BR70-51-0L0B
- From 9-1-92 to 5-1-93  
Right BR70-51-0K0B  
Left BR70-51-0L0B

- From 5-1-93 to 7-1-93  
Right BR93-51-0K0B  
Left BR70-51-0L0B

- 3 Housing R BR70-51-03X  
L BR70-51-04X
- 4 Holder, Bulb R/L BM89-51-0A3A
- 5 Bulb R/L 0000-11-9004-90  
(a) Included w/Lamp Assy

## SIDE MARKER LAMP



035-01252

- 1 Lamp Assy R 8BBJ-51-060  
L 8BBJ-51-070
- 2 Lens & Housing Assy R BR70-51-06X  
L BR70-51-07X
- 3 Protector (a) R B455-51-065  
L B455-51-075  
(a) Included w/Lens & Housing Assy
- 4 Socket & Wire R/L BR70-51-064
- 5 Bulb R/L 0000-11-1157  
(a) Included w/Lamp Assy


## HOOD

Illustration Located in Next Column

- 1 Panel, Hood  
Hatchback BR93-52-310C  
Sedan  
SOHC Eng  
To 7-1-93 BR70-52-310F  
From 7-1-93 BB0S-52-310B  
DOHC Eng  
To 9-1-92 BR70-52-310F  
From 9-1-92 to 7-1-93 BR70-52-310F  
From 7-1-93 BB0S-52-310B



# MAZDA 323/PROTEGE 1990-94

## HOOD Cont'd



- Insulator, Hood B528-68-601
- 2 Rubber, Cushion R/L UB39-56-740
- 3 Rubber, Stopper R/L LA01-56-786A
- 4 Hinge, Hood Hatchback R B467-52-410D
- Sedan L B467-52-420D
- R B455-52-410E
- L B455-52-420E
- 5 Latch Hatchback BR93-56-620E
- Sedan BR70-56-620G
- SOHC Eng 90-92 BR70-56-620G
- DOHC Eng 93-95 BR70-56-620G
- 6 Cable, Release B455-56-720B
- 7 Clip, Release Cable (2) D001-56-731
- 8 Fastener, Release LA01-56-631
- 9 Rod, Support B455-56-651
- 10 Holder, Rod Front B455-56-693
- 11 Holder, Rod Rear B092-52-518
- 12 Deflector Assy, Hood Hatchback R B467-56-730C
- L B467-56-740C
- Sedan 90-92 R B455-56-730B
- L B455-56-740B
- 93-95 R B595-56-730
- L B595-56-740
- Clip, Deflector (3/Side) R/L B455-56-741
- †Included w/Hood Deflector Assy
- 13 Weatherstrip Assy, Front B455-56-750B
- Clip, W/Strip (a) (7) B455-56-741
- (a) Included w/Front Weatherstrip Assy
- 14 W/Strip, Rear B455-56-760A
- Fastener Assy, Weatherstrip (b) (2) G031-58-762
- (b) Included w/Rear Weatherstrip Assy


- Man Trans B61W-15-210
- Auto Trans BP05-15-210
- BP26-15-210A
- AWD
- 7 Blade, Fan FWD 1.6L Eng FEH5-15-140
- Man Trans B6S8-15-140A
- Auto Trans
- 1.8L Eng B6S8-15-140A
- Man Trans B6S8-15-140A
- Auto Trans B61F-15-140
- BP26-15-140A
- AWD
- 8 Motor, Fan FWD 1.6L Eng B366-15-150B
- Man Trans B6S8-15-150C
- Auto Trans
- 1.8L Eng B6S8-15-150C
- Man Trans B61F-15-150A
- Auto Trans BP26-15-150C
- AWD
- 9 Hose, Rad Upper 1.6L Eng B366-15-186A
- 1.8L Eng
- SOHC B366-15-186A
- DOHC Eng B6S7-15-186A
- 10 Hose, Rad Lower B366-15-185A
- 11 Tank Assy, Coolant B366-15-350D
- 12 Cap, Tank† B6S7-15-355A
- 13 Bracket, Tank† B366-15-371A
- 14 Lever, Tank† B6S7-15-355A
- †Included w/Coolant Tank Assy
- Pump, Water 1.6L Eng 8AB7-15-010
- 1.8L Eng
- SOHC Eng 8AB7-15-010
- DOHC Eng 8AB8-15-010
- Pulley, Water Pump B366-15-131A



## A/C REFRIGERANT CAPACITIES

A/C R-12 Refrigerant Capacity  
 1990-92: 26.5-28 Ozs (1.65-1.75 Lbs)  
 1993-95: 28 Ozs (1.75 Lbs)

## A/C /HEATER/VENTILATION




- 1 Condenser BB7C-61-480
- 2 Receiver/Drier BR70-61-500
- 3 Compressor Assy SOHC Eng BR70-61-450A
- DOHC Eng BR74-61-450A
- Compressor† BR70-61-K00
- 4 Clutch Assy† SOHC Eng B455-61-L10
- DOHC Eng B461-61-L10
- †Included w/Compressor Assy
- 5 Hose, Suction 1.6L Eng BR71-61-461B
- 1.8L Eng BR70-61-461B
- 6 Hose, Return 1.6L Eng BR71-61-462A
- 1.8L Eng BB7A-61-462
- 7 Pipe, Condenser Tube, A/C BR70-61-464A
- 8 Upper Man Trans BR70-61-465B
- Auto Trans BR72-61-465B
- Lower BR70-61-467A
- 9 Fan, Condenser BR70-61-710A
- 10 Bracket, Fan BR70-61-71X

†Included w/Compressor Assy


- 12 Evaporator Assy BR70-61-520B
- 13 Case, Evap Upper† BR70-61-J01
- 14 Case, Evap Lower† BR70-61-J02
- 15 Core, Evaporator† BR70-61-J10A
- 16 Insulator† HA14-76-707
- 17 Valve, Expansion† BR70-61-J14
- †Included w/Evaporator Assy
- 18 Heater Assy BR70-61-130

- 19 Core, Heater† BR70-61-A10
- Case, Heater†
- 20 Right BR70-61-A01
- Left BR70-61-A02
- 21 BR70-61-A11A
- 22 Lining, Heater† (2) BR70-61-A20
- 23 Link Set, Temp† BR70-61-A30
- 24 Link Set, Mode†
- †Included w/Heater Assy




- 25 Blower Assy, Heater EA77-61-140
- 26 Case, Blower Upper† BR70-61-B01
- 27 Case, Blower Lower† BR70-61-B02
- 28 Fan† BR70-61-B10
- 29 Resistor, Blower† BR70-61-B15
- 30 Link† BR70-61-B20
- †Included w/Heater Blower Assy

## COOLING



- 1 Radiator Assy† FWD B61S-15-200E
- Man Trans B61N-15-200D
- Auto Trans BP02-15-200H
- 1.6L Eng
- 1.8L Eng
- AWD BP45-15-200B
- Man Trans BP46-15-200A
- Auto Trans
- †Order by Application
- 2 Cap, Radiator (a) Calsonic Brand D316-15-205
- Denso Brand F8B7-15-205
- 3 Mount, Rubber (a) Man Trans R/L B366-15-202B
- Calsonic Brand R/L B541-15-202A
- Denso Brand R/L B61N-15-202A
- Auto Trans R/L B61N-15-202A
- (a) Included w/Radiator Assy
- 4 Brkt, Rad Upper R/L B6S7-15-240B
- 5 Brkt, Rad Lower R/L B366-15-230
- 6 Shroud, Fan FWD B61W-15-210
- 1.6L Eng
- 1.8L Eng

## FRONT FENDER




# MAZDA 323/PROTEGE 1990-94

1 Fender Assy	Hatchback	R BR93-52-110B L BR93-52-210C
	Sedan	R B456-52-110B L B456-52-210C
2 Bracket, Lamp <sup>¶</sup>		R B455-52-180 L B455-52-280A
	<i>¶</i> Included w/Fender Assy	
Moulding, Side	Adhesive	
	Hatchback	R B4Y7-50-681 L B4Y7-50-691
Sedan	w/Red Line	R BAYG-50-681 L BAYG-50-691
	w/o Red Line	R B4Y5-50-681 L B4Y5-50-691
Nameplate	"DX"	
	Light Gold	R/L BR70-51-761-71
	Light Gray	R/L BR70-51-761-85
	Dark Gray	R/L BR70-51-761-86
	"LX"	
	Light Gold	R/L BR71-51-761-71
	Light Gray	R/L BR71-51-761-85
	Dark Gray	R/L BR71-51-761-86
	"SE"	
	Light Gold	R/L BR72-51-761-71
	Light Gray	R/L BR72-51-761-85
	Dark Gray	R/L BR72-51-761-86
"GT"	Canada	
	Light Gold	R/L N.A.
	Light Gray	R/L N.A.
"DOHC 16-VALVE"	Light Gold	B516-51-771A-71
	Light Gray	B516-51-771A-85
	Dark Gray	B516-51-771A-86
3 Shield, Splash		R B455-56-131B L B455-56-141B
		R B455-51-840C L B455-51-850C

4 Bar, Lower Tie <sup>¶</sup>		B455-53-16XE
	<i>¶</i> Included w/Radiator Support Assy	
5 Support, Hood Latch		B455-53-35YA
		R B455-53-325B L B455-54-325B
6 Plate, Side Panel		R BR70-56-111A L BR70-56-121A
7 Cover, Under		

Positive	N.A.
Negative	N.A.


## CRUISE CONTROL SYSTEM



1 Actuator Assy	BR70-66-310B
2 Brkt. Actuator Front <sup>¶</sup>	BR70-66-3A1B
3 Brkt. Actuator Rear <sup>¶</sup>	BR70-66-3A2
4 Holder, Wire <sup>¶</sup>	BR70-66-3A8A
<i>¶</i> Included w/Actuator Assy	
5 Bracket, Lower	BR70-66-3AXA
6 Wire, Cruise Control	BR70-66-311E
7 Tube, Cruise Control	BR70-66-361A
8 Control, Cruise	BR70-66-320A


## WHEEL

### STEEL WHEEL




1 Wheel, Spare	9965-15-404
2 Wheel, Steel	
13x5"	
Base Model	9965-70-5030
DX, SE Model	9965-73-503
14x5-1/2"	9965-A9-554
3 Cap, Wheel	
13" Wheels	
DX, SE Model	B458-37-170A
LX Model	BB7E-37-170
14" Wheels	B459-37-170A
4 Cap, Hub	B457-37-170A
5 Cap, Assy, Center	
13" Wheels	B455-37-190
14" Wheels	B461-37-190A
7 Emblem, Center <sup>¶</sup>	B001-37-192
<i>¶</i> Included w/Center Cap Assy	
Stem, Valve	9963-60-4130
Nut, Lug	
Standard	B002-37-160A
Chrome	0603-26-161A

### ALLOY WHEEL




Wheel Assy	
1 13x5"	8BB8-37-600
2 14x5-1/2"	90-91 8BB7-37-600 92-95 B599-37-192C
3 Cap, Center <sup>¶</sup>	
13" Wheels	B460-37-190B
4 14" Wheels	B461-37-190A
5 Stem, Valve <sup>¶</sup>	9963-60-4130

## UNDERHOOD DIMENSIONS




## FRONT INNER STRUCTURE


### FRONT



1 Support Assy, Radiator	BR70-53-100J
2 Bar, Upper Tie <sup>¶</sup>	B455-53-150D
3 Panel, Side <sup>¶</sup>	R BR70-53-120E L BR70-54-120F



1 Apron Assy	
FWD	R BR70-53-200A L BR70-54-200A
AWD	R BA1C-53-200 L BA1C-54-200
2 Panel, Apron <sup>¶</sup>	R BS06-53-210D L BS06-54-210C
3 Frame Assy, Apron <sup>¶</sup>	
FWD	R BR70-53-300H L BR70-54-300M
AWD	R BA1C-53-300L L BA1C-54-300P
Bolt, Member <sup>¶</sup> (a)	90-93 R/L B455-53-319 94-95 R/L B456-53-319
<i>¶</i> Included w/Apron Assy	
(a) Included w/Apron Frame Assy	
4 Reinf, Apron	R B455-53-281A L B455-54-281A
5 Guard, Splash Front	
FWD	R B455-56-311B L B455-56-321B
AWD	R B528-56-31X L B528-56-321B
6 Guard, Splash Rear	
FWD	R BC1D-56-114 L B455-56-115
AWD	R B528-56-312A L B528-56-322A
7 Bracket, Bumper	R B455-53-335A L B455-54-335A
8 Hook, Tie-Down	R BR70-53-36YF L BR70-54-36YF



9 Tray, Battery	
1990-91	B465-56-040C
FWD	B542-56-040A
AWD	B467-56-040B
1992-94	
10 Box, Battery	
50 Amp Battery	PN40-18-591
55 Amp Battery	PN41-18-591A
11 Duct, Battery	
FWD	B658-18-596A
AWD	BP47-18-596
12 Clamp, Battery	B465-56-03XA
13 Bolt, Battery	
Front	B180-56-034A
Rear	B455-56-034
14 Battery	N.A.

# MAZDA 323/PROTEGE 1990-94


## WHEEL Cont'd

### ALLOY WHEEL Cont'd

†Included w/Wheel Assy

<b>6 Cap, Wheel</b>	
13" Wheels	
DX, SE Model	B458-37-170A
LX Model	BB7E-37-170
14" Wheels	
<b>7 Cap, Hub Stem, Valve Nut, Lug</b>	
Standard	B002-37-160A
Bright	0603-26-161A


## FRONT SUSPENSION




<b>1 Rotor, Brake</b>	
FWD	
SOHC Eng	R/L B26Y-33-25XA
DOHC Eng	R/L BB7E-33-25XD
AWD	R/L B530-33-25XE
<b>Nut, Lock</b>	
<b>2 Hub, Drive</b>	
<b>3 Caliper, Brake</b>	
FWD	
SOHC Eng	R B4Y2-33-98ZR
	L B4Y2-33-98ZR
DOHC Eng	R BR74-33-98ZR
	L BR74-33-98ZR
AWD	R BR74-33-98ZR
	L BR74-33-98ZR
<b>Hose, Brake</b>	
FWD	R/L B455-43-980B
AWD	R/L B461-43-980C
<b>4 Knuckle Assy, Steering</b>	
FWD	
SOHC Eng	
To 1-1-92	R B455-33-020A
	L B455-33-030A
From 1-1-92 to 3-9-93	
Right	B455-33-020A
Left	B455-33-030A
From 3-9-93	R B01L-33-020B
	L B01L-33-030B
DOHC Eng	
To 1-1-92	R BR74-33-020C
	L BR74-33-030C
From 1-1-92 to 3-9-92	
Right	BR74-33-020C
Left	BR74-33-030C
From 3-9-92	R B01A-33-020B
	L B01A-33-030B
AWD	R BR74-33-020C
	L BR74-33-030C
<b>5 Shield, Splash†</b>	
To 6-1-93	R B01A-33-261B
	L B01A-33-271B
From 6-1-93	R B01A-33-261B
	L B01A-33-271B
†Included w/Steering Knuckle Assy	
<b>6 Bearing, Wheel</b>	R/L B455-33-047D-MV
<b>7 Seal, Bearing</b>	R/L G304-33-065
<b>8 Ring, Retaining</b>	R/L B21M-33-048

Illustration Located in Next Column

<b>9 Strut</b>	
FWD	
1.6L Eng	R BR70-34-700F
	L BR70-34-900F
1.8L Eng	R BR70-34-700F
	L BR70-34-900F
AWD	R BA1E-34-700A
	L BA1E-34-900A
<b>10 Spring, Coil†</b>	
Hatchback	
Man Trans	R/L B458-34-011A
Auto Trans	R/L B463-34-011A
Sedan	
FWD	
Man Trans	R/L B463-34-011A
Auto Trans	R/L BR72-34-011A
AWD	
Man Trans	R/L BR72-34-011A
Auto Trans	R/L BR75-34-011A



†Order by Application	
<b>11 Bumper, Stop</b>	R/L B455-34-111B
<b>12 Seat, Rubber</b>	R/L B455-34-012
<b>13 Seat, Spring</b>	R/L B455-34-340A
<b>14 Bushing, Mtg</b>	R/L B455-34-38XB
<b>15 Mount, Strut</b>	R/L B455-34-380D
<b>16 Cap, Damper</b>	R/L 1011-34-019
<b>17 Arm Assy, Lower Control</b>	
1990-91	
FWD	R B455-34-300E
	L B455-34-350E
AWD	R B530-34-300A
	L B530-34-350A
1992-95	
Std Duty	
To 3-9-93	R BR70-34-300B
	L BR70-34-350B
From 3-9-93	R B455-34-300E
	L B455-34-350E
Hvy Duty	
To 3-9-93	R BS06-34-300
	L BS06-34-350
From 3-9-93	R B620-34-300C
	L B620-34-350C
<b>18 Joint, Ball†</b>	
To 3-9-93	R/L B455-34-550
From 3-9-93	R/L BTDA-34-550
<b>Bolt, Ball Joint†</b>	R/L B455-34-349A
†Included w/Lower Control Arm Assy	
<b>19 Bolt, Lower Arm</b>	R/L B455-34-113




<b>20 Bar, Stabilizer</b>	
FWD	
Std Duty	B459-34-151
Hvy Duty	B461-34-151B
AWD	BA1C-34-151A
<b>21 Bushing, Stabilizer</b>	
FWD	
Std Duty	R/L B459-34-156A
Hvy Duty	R/L EA03-34-156
AWD	R/L B461-28-156A
<b>22 Bracket, Stabilizer</b>	
To 6-1-94	R/L B461-34-155A
From 6-1-94	R/L BC1D-34-155B
<b>23 Crossmember, Susp</b>	
FWD	EA01-34-800G
AWD	B528-34-800G

## FRONT DRIVE AXLE

Illustration Located in Next Column

<b>1 Shaft Assy, Axle</b>	
FWD	
1.6L Eng	R FZ24-25-400R-0A




		L F024-25-600R-0H
1.8L Eng		
SOHC Eng	R FS17-25-400R-0F	
	L FS17-25-600R-0F	
DOHC 1990-91		
Man Trans	R F037-25-500R-0B	
	L F037-25-600R-0D	
Auto Trans	R F037-25-500R-0B	
	L F017-25-600R-0E	
DOHC 1992-95		
Right		
To 3-1-92	F037-25-400R-0A	
From 3-1-92	F037-25-500R-0B	
Left		
To 7-1-92	F037-25-600R-0D	
From 7-1-92	F037-25-600R-0D	
AWD		
Man Trans	R F051-25-500	
	L F051-25-600D	
Auto Trans	R F059-25-500B	
	L F052-25-600B	
<b>2 Joint Set, Outer†(b)</b>		
FWD		
1.6L Eng	R F024-22-510A	
	L F024-22-610A	
1.8L Eng		
SOHC Eng		
To 7-12-93	R FS17-22-510	
	L FS17-22-610	
From 7-12-93	R FS17-22-510C	
	L FS17-22-610C	
DOHC Eng		
Man Trans	R F037-22-510B	
	L F037-22-610A	
Auto Trans	R F037-22-510B	
	L F017-22-610A	
AWD		
Man Trans	R F051-22-510A	
	L F051-22-610A	
Auto Trans	R F059-22-510B	
	L F052-22-610A	
<b>3 Boot, Outer†(a) (b)</b>		
FWD		
1.6L Eng	R/L BS10-V9-050-9U	
1.8L Eng		
SOHC Eng	R/L BS05-V9-050	
DOHC Eng	R/L BS40-V9-050-9U	
AWD	R/L BS20-V9-050-9U	
(a) Included w/Outer Joint Set		
<b>4 Joint Set, Inner†(b)</b>		
FWD		
1.6L Eng	90-92 R/L FZ02-22-520A	
	93-95 R/L FZ02-22-520A	
1.8L Eng		
SOHC Eng	90-92 R FS17-22-520C	
	L FS17-22-620	
	93-95 R FS17-22-520C	
	L FS17-22-620B	
DOHC Eng		
1990-92	R F037-22-520	
	L F017-22-620C	
1993-95	R F037-22-520	
Man Trans	L F037-22-620C	
Auto Trans	R F037-22-520	
	L F017-22-620C	
AWD	R F051-22-520	
	L F051-22-620C	
<b>5 Boot, Inner†(a) (b)</b>		
FWD		
1.6L Eng	R/L F061-22-540-9U	
1.8L Eng	R/L FS17-22-540	
AWD	R/L G071-22-540	
(a) Included w/Inner Joint Set		
<b>6 Damper, Dynamic†(b)</b>		
1.6L Eng	F002-25-411B	
1.8L Eng	F018-25-411	
†Included w/Axle Shaft Assy		
<b>7 Shaft Assy, Joint (b)</b>		
Man Trans (DOHC Eng)	F037-25-700	
Auto Trans (DOHC Eng)	F047-25-700	
<b>8 Seal, Dust Inner†(b)</b>	F002-25-744	
<b>9 Bearing, Ball†(b)</b>	9960-68-2063	
<b>10 Brkt, Shaft†(b)-Serviced w/Joint Shaft Assy</b>	F002-25-742	
<b>11 Seal, Dust Outer†(b)</b>		
†Included w/Joint Shaft Assy		

# MAZDA 323/PROTEGE 1990-94

(b) Order by Application

## FRONT STEERING LINKAGE/GEAR


### MANUAL



002-04079

- |                       |                 |
|-----------------------|-----------------|
| 1 Gear Assy           | BR70-32-110A    |
| 2 Rod, Inner Tie†     | R/L B455-32-24X |
| 3 Boot, Dust†         | R/L B455-32-125 |
| 4 Rack, Gear†         | BR70-32-119     |
| 5 Bushing, Shaft†     | BF67-32-114     |
| 6 Housing, Gear†      | BR70-32-120     |
| 7 Pinion, Gear†       | BR70-32-122     |
| 8 Cover, Lever†       | B455-32-112     |
| 9 Rubber, Mounting†   |                 |
| 9 Right               | B455-32-124     |
| 10 Left               | B455-32-123     |
| 11 Right              | B455-32-134     |
| 12 Left               | B455-32-133     |
| †Included w/Gear Assy |                 |
| 13 End, Tie Rod       | R/L 8AB2-32-280 |
| Seal, Dust            | R/L B455-32-279 |

### POWER




002-04080

- |                    |                 |
|--------------------|-----------------|
| 1 Gear Assy        |                 |
| FWD                | BR71-32-110L    |
| AWD                | BA1C-32-110C    |
| 2 Rod, Inner Tie†  |                 |
| FWD                | R B456-32-24X   |
| AWD                | L B456-32-25X   |
|                    | R B528-32-24X   |
|                    | L B528-32-25X   |
|                    | R/L B456-32-125 |
| 3 Boot, Dust†      |                 |
| 4 Rack, Gear†      |                 |
| FWD                | BR71-32-119     |
| AWD                | BA1C-32-119     |
| 5 Valve, Gear†     |                 |
| FWD                |                 |
| To 4-1-93          | BR71-32-380     |
| From 4-1-93        | BR72-32-380     |
| AWD                | BA1C-32-380     |
| 6 Cover, Lever†    | B456-32-112     |
| 7 Insulator, Gear† |                 |
| Right              | B456-32-124     |
| FWD                |                 |
| AWD                | B528-32-124     |

- |                       |     |              |
|-----------------------|-----|--------------|
| 8 Left                |     | B595-32-123  |
| FWD                   |     | B528-32-123  |
| AWD                   |     |              |
| Bracket, Mounting†    |     |              |
| 9 Right               |     | B456-32-134  |
| FWD                   |     | B528-32-134  |
| AWD                   |     |              |
| 10 Left               |     | B456-32-133  |
| FWD                   |     | B528-32-133  |
| AWD                   |     |              |
| 11 Bracket, Hose†     |     | BR71-32-18X  |
| FWD                   |     | BA1C-32-18X  |
| AWD                   |     |              |
| 12 Pipe, Fluid†       |     |              |
| Right Turn            |     | BR71-32-6G0A |
| FWD                   |     | BA1C-32-6G0  |
| AWD                   |     |              |
| 13 Pipe, Pressure†    |     | BR71-32-451  |
| FWD                   |     | BA1C-32-451  |
| AWD                   |     |              |
| 14 Pipe, Fluid†       |     |              |
| Left Turn             |     | BR71-32-481  |
| FWD                   |     | BA1C-32-481  |
| AWD                   |     |              |
| †Included w/Gear Assy |     |              |
| 15 End, Tie Rod       | R/L | 8AB2-32-280  |


## STEERING PUMP



035-02472

- |                                       |  |                 |
|---------------------------------------|--|-----------------|
| 1 Pump Assy                           |  |                 |
| FWD                                   |  | B456-32-600G    |
| 1.6L Eng                              |  | BR71-32-600R-0D |
| 1.8L Eng                              |  | B530-32-600A    |
| AWD                                   |  |                 |
| 2 Pulley, Pump†, Serviced w/Pump Assy |  | B456-32-614     |
| 3 Bracket, Pump†                      |  |                 |
| 4 Pipe, Suction†                      |  | B456-32-5M0     |
| 1.6L Eng                              |  | BR71-32-5M0     |
| 1.8L Eng                              |  | B456-32-613A    |
| 5 Nipple, Hose†                       |  | B456-32-230     |
| 6 Sensor, Pressure†                   |  |                 |
| †Included w/Pump Assy                 |  |                 |
| 7 Bracket, Pump Side                  |  | B456-32-60YB    |
| 8 Bracket, Pump Rear                  |  | B25D-32-680     |
| 9 Reservoir Assy                      |  | BR71-32-690D    |
| 10 Cap, Reservoir†                    |  |                 |
| To 12-1-91                            |  | B01C-32-691     |
| From 12-1-91                          |  | G211-32-618A    |
| †Included w/Reservoir Assy            |  |                 |
| 11 Strainer, Reservoir                |  | BR71-32-503A    |
| 12 Pipe Assy, Cooling                 |  | BR71-32-470B    |
| 13 Hose, Return Front†                |  | B456-32-684A    |
| 14 Hose, Return Rear†                 |  | B456-32-683A    |
| †Included w/Cooling Pipe Assy         |  |                 |
| 15 Hose, Suction                      |  | BR71-32-688     |
| 16 Hose Assy                          |  | B456-32-410F    |
| 17 Mount, Hose Assy†                  |  | H267-32-425     |
| †Included w/Hose Assy                 |  |                 |
| 18 Hose, Pressure                     |  | BR71-32-49YC    |
| 19 Hose, Return                       |  | B456-32-6F0A    |


## STEERING WHEEL/COLUMN



035-02473

- |                                 |  |              |
|---------------------------------|--|--------------|
| 1 Wheel Assy, Steering          |  | BR71-32-980B |
| w/Cruise Control                |  |              |
| w/o Cruise Control              |  | BR70-32-980B |
| Base, GT Model                  |  | B456-32-980A |
| Sport Model                     |  |              |
| 2 Cover, Steering Wheel†        |  | BR71-32-040  |
| w/Cruise Control                |  |              |
| w/o Cruise Control              |  | BR71-32-040  |
| Base, GT Model                  |  | B461-32-040  |
| Sport Model                     |  | B456-32-040  |
| †Included w/Steering Wheel Assy |  |              |
| 3 Cap Assy, Horn                |  | BR71-32-800C |
| w/Cruise Control                |  |              |
| w/o Cruise Control              |  | BR70-32-800  |
| Base Model                      |  | B461-32-800A |
| GT Model                        |  | B456-32-800  |
| Sport Model                     |  | BR70-66-3D1C |
| 4 Switch, Cruise Control†       |  |              |
| †Included w/Horn Cap Assy       |  |              |

035-02474



- |  |  |              |
|--|--|--------------|
| 5 Cover Assy, Column Upper             |  | BR72-60-220A |
| w/Cruise Control                       |  | BR70-60-220  |
| w/o Cruise Control                     |  |              |
| 6 Cover Assy, Column Lower             |  | BR70-60-230  |
| w/Key Lamp                             |  | BR93-60-231  |
| w/o Key Lamp                           |  |              |
| 7 Label, Indicator†                    |  | BR70-60-222  |
| w/Cruise Control                       |  | BA70-60-222  |
| w/o Cruise Control                     |  |              |
| †Included w/Column Upper Cover Assy    |  |              |
| 8 Case, Lamp (a)                       |  | B456-60-245  |
| 9 Lens, Column (a)                     |  | B456-60-246  |
| (a) Included w/Column Lower Cover Assy |  |              |
| 10 Bulb & Socket                       |  | B456-60-223  |
| 11 Ring, Key Cylinder                  |  | LA01-60-261  |
| 12 Switch, Combination                 |  |              |
| w/Intermittent Wiper                   |  |              |
| w/Rear Wiper                           |  | BB7B-66-120  |
| w/Cruise Control                       |  |              |
| w/o Cruise Control                     |  | BB7A-66-120  |
| Standard, DX, SE Model                 |  | BB7B-66-120  |
| LX Model                               |  |              |
| w/o Rear Wiper                         |  |              |
| w/Cruise Control                       |  | BR75-66-120D |
| w/o Cruise Control                     |  | BR72-66-120G |
| w/o Intermittent Wiper                 |  | BR70-66-120G |
| Switch, Ignition                       |  | B455-66-151A |
| 13 Column Assy                         |  |              |
| w/Tilt Column                          |  | BR71-32-100G |
| w/o Tilt Column                        |  | BR70-32-100E |
|  |  | BS07-32-175A |
| 14 Bracket, Shaft Upper†               |  | BR71-32-140  |
| 15 Bracket, Shaft Lower†               |  | B456-32-171  |
| †Included w/Tilt Steering Column Assy  |  |              |
| 17 Shaft, Intermediate                 |  |              |
| FWD                                    |  | BR71-32-090E |
| AWD                                    |  | BA1C-32-090  |
| 18 Cover, Steering Shaft               |  |              |
| FWD                                    |  | BR70-32-210E |
| AWD                                    |  | BA1C-32-210  |
|  |  | BR70-32-216  |
| 19 Plate, Strg Upper                   |  | BR70-32-212  |
| 20 Plate, Strg Lower                   |  | BR70-32-215C |
| 21 Cover, Lever                        |  |              |

## ENGINE

### 1.6L ENG

- |                       |       |               |
|-----------------------|-------|---------------|
| Pulley, Crankshaft†   | 90-91 | B6S7-11-401A  |
|                       | 92-95 | B6S8-11-401   |
| †Order by Application |       |               |
| Cover, Timing Belt    |       |               |
| Upper                 |       | B630-10-510B  |
| Lower                 |       | B630-10-500D  |
| Pan, Eng Oil          |       | B366-10-400A  |
| Gasket, Eng Oil Pan   | R/L   | B541-10-427-8 |
| Sealant, Eng Oil Pan  |       | 8527-77-739   |

### 1.8L ENG

- |                    |         |  |
|--------------------|---------|--|
| Pulley, Crankshaft | 1990-91 |  |
|--------------------|---------|--|

# MAZDA 323/PROTEGE 1990-94

ENGINE Cont'd	
1.8L ENG Cont'd	
SOHC Eng	B6S7-11-401A
DOHC Eng	BP05-11-401
1992-95	
SOHC Eng	B6S8-11-401
DOHC Eng	B577-11-401
<b>Cover, Timing Belt</b>	
SOHC Eng	
Upper	B630-10-510B
Lower	B630-10-500D
DOHC Eng	
Upper	BJ01-10-510C
Lower	B660-10-501E
Center	B660-10-521B
<b>Pan, Eng Oil</b>	
Man Trans	BP01-10-400K
Auto Trans	BP02-10-400H
<b>Gasket, Eng Oil Pan</b>	R/L B541-10-427-8
<b>Sealant, Eng Oil Pan</b>	8527-77-739

## ENGINE MOUNTS

1.6L ENG		
1	Mount, Eng Right	BR70-39-060B
2	Mount, Eng Left	
	Man Trans	B456-39-040C
	Auto Trans	B456-39-040C
3	Mount, Eng Front	B455-39-050B
4	Mount, Rear	
	Man Trans	B596-39-100B
	Auto Trans	B599-39-100A
5	Brkt, Mount Right	B461-39-030C
6	Brkt, Mount Left	
	Man Trans	B455-39-010B
	Auto Trans	B458-39-010F
	<b>Brkt, Mount Front</b>	
8	Man Trans	B455-39-020A
9	Auto Trans	B456-39-020A
10	Brkt, Eng Mount	R B455-53-37XC
11	Clip	BF67-67-996
12	Crossmember, Susp	B455-39-800D

1.8L ENG		
1	Mount, Eng Right	
	FWD	B455-39-060E
	AWD	B528-39-060B
2	Mount, Eng Left	
	FWD	
	Man Trans	B456-39-040C
	Auto Trans	B456-39-040C
	AWD	
	Man Trans	B528-39-040A
	Auto Trans	B529-39-040A
3	Mount, Eng Front	

FWD	B455-39-050B	
AWD	B455-39-050B	
<b>Mount, Rear</b>		
FWD		
4	Man Trans	B455-39-100E
5	Auto Trans	B599-39-100A
AWD		
	Man Trans	B528-39-100B
	Auto Trans	B529-39-100C
6	Brkt, Mount Right	BR70-39-030D
7	Brkt, Mount Left	
FWD		
	Man Trans	B455-39-010B
	SOHC Eng	BR74-39-010C
	DOHC Eng	B458-39-010F
	Auto Trans	B528-39-010A
	AWD	
<b>Brkt, Mount Front</b>		
8	Man Trans	B455-39-020A
9	SOHC Eng	B456-39-020A
10	DOHC Eng	
<b>Bracket, Support Eng Mtg</b>		
Man Trans		
To 3-1-94	BR74-39-090	
From 3-1-94	BC1F-39-090	
11	Brkt, Eng Mount	R B455-53-37XC
12	Clip	BF67-67-996
13	Crossmember, Susp	
FWD	B455-39-800D	
AWD	B528-39-800D	

## AIR CLEANER

1	Cleaner Assy, Air	B6S7-13-320A
2	Cover, Air Cleaner	B6S7-13-201
3	Element, Cleaner	B6S7-13-240-9U
	*Included w/Air Cleaner Assy	
4	Meter, Air Flow	
	SOHC Eng	B6S7-13-210R-0A
	DOHC Eng	BP05-13-210R-00
5	Gasket, Meter	B6S7-13-211A
6	Joint, Rubber	B6S7-13-245A
7	Chamber, Resonance	
	SOHC Eng	BP01-13-195A
	DOHC Eng	B6S7-13-195B
8	Hose, Air	
	SOHC Eng	BP01-13-221A
	DOHC Eng	B6S7-13-221B
9	Hose, Resonator Duct	B6S7-13-228
10	Duct, Resonance	B6S7-13-18XD
11	Duct, Fresh Air	
	SOHC Eng	
	1.6L Eng	B6S7-13-200C
	1.8L Eng	BP01-13-200D
	DOHC Eng	BP01-13-200D

## EXHAUST

<b>Manifold, Exhaust</b>	
1.6L Eng	
w/Calif Emission	
1990-92	B61K-13-450C
1993-94	B67K-13-450A
w/o Calif Emission	B61K-13-450C
1.8L Eng	
SOHC Eng	BP01-13-450D
DOHC Eng	90-93 BP05-13-450E
	94-95 BPE1-13-450
<b>Pipe, Exhaust Front</b>	
1990-91	
1.6L Eng	B6E5-40-100A
1.8L Eng	
SOHC Eng	BP02-40-100G
DOHC Eng	B684-40-100J
1992-95	
1.6L Eng	BP04-40-500B
1.8L Eng	
SOHC Eng	BP04-40-500B
DOHC Eng	92-93 BP04-40-500B
	94-95 BP51-40-500
<b>Converter, Catalytic</b>	

1990-91		
1.6L Eng	B6Y5-20-600	
1.8L Eng		
FWD	BPY1-20-600A	
AWD	BP45-20-600B	
1992-95		
1.6L Eng	B6Y5-20-600	
1.8L Eng	BPY1-20-600A	
	*Order by Application	
<b>Pipe, Intermediate</b>		
1.6L Eng	B685-40-300B	
1.8L Eng		
SOHC Eng		
Hatchback	BP05-40-300	
Sedan	BP01-40-300	
DOHC Eng	B683-40-300C	
<b>Muffler w/Pipe</b>		
1.6L Eng	90-91 B6E5-40-100A	
	92-95 B6E5-40-100A	
1.8L Eng		
SOHC Eng	BP02-40-100G	
DOHC Eng	B684-40-100J	

## EMISSION SYSTEM

<b>Canister, Vapor</b>	BP01-13-970	
<b>Bracket, Canister</b>	B6S7-13-961	
<b>Valve, Solenoid</b>	BP01-18-740A	
<b>Bracket, Solenoid Valve</b>	BP51-18-835A	
<b>Rubber, Mounting (2)</b>	F285-13-363	
<b>Valve, 3 Way</b>	BP51-18-741A	
	*Order by Application	
<b>Valve, Air Control</b>		
1.6L Eng	B6S7-13-190B	
1.8L Eng		
Man Trans	BP01-13-190A	
Auto Trans	BP02-13-190A	

## ELECTRICAL

### ALTERNATOR

<b>Alternator Assy</b>		
New	B366-18-300R-00	
Remanufactured	B366-18-300R-00	
	*Remanufactured Part. Contact Dealer for Core Charge & Exchange Information	
<b>Pulley, Alternator (a)</b>	B366-18-W10	
	(a) Included w/Alternator Assy	
<b>Strap, Alternator</b>	BP01-18-361	
<b>Belt, Drive</b>		
1.6L Eng	B6S7-18-381B-9U	
1.8L Eng	B61H-18-381A-9U	

### BATTERY

<b>Battery</b>	0000-80-026R-WB	
	*Order by Application	
<b>Cable, Battery</b>		
Positive	N.A.	
Negative	N.A.	

### HORN

<b>Horn</b>	
1990-91	FB03-66-790A
1992-95	
To 8-1-92	B596-66-790A
From 8-1-92	B596-66-790A

### IGNITION

<b>Module, Main Computer</b>	(a)	
Man Trans	BP10-18-881R	
Auto Trans	BPB2-18-881R	
	*Remanufactured Part. Contact Dealer for Core Charge & Exchange Information	
	(a) Order by Application	
<b>Coil, Ignition</b>	B6S7-18-10XA	

## WINDSHIELD

1	Glass, Windshield	
	Mazda	

# MAZDA 323/PROTEGE 1990-94

Hatchback Clear	B467-63-901A
Blue Tint To 2-4-93	BR93-63-901A
From 2-4-93	B469-63-901A
Sedan Clear	B457-63-901A
Blue Tint	B457-63-901A
<b>2 Dam, Windshield</b>	90-91 GT8T-50-894
	92-95 B481-50-894
<b>3 Stopper, Glass</b>	BR70-50-G30
<b>Spacer, Glass</b>	
Black	R/L B455-50-891A
White	R/L EA01-50-891A
<b>Moulding, Reveal</b>	
4 Hatchback	B4Y7-50-601A
5 Sedan	BW5B-50-601A
<b>6 Retainer, Moulding</b>	
Hatchback	BTE4-50-6B1
Sedan	BTE4-50-6B1
<b>Moulding, Inside Garnish</b>	
Hatchback Gray	R BR93-68-160E-06
	L BR93-68-170E-06
Gray/Taupe	R BR93-68-160E-35
	L BR93-68-170E-35
Sedan Gray	R BR70-68-160D-06
	L BR70-68-170D-06
Gray/Taupe	R BR70-68-160D-35
	L BR70-68-170D-35
<b>Mirror, Rear View</b>	
Hatchback	B460-69-220A
Sedan	B461-69-220
<b>Visor, Sun w/Mirror</b>	
To 2-1-94	
Gray	R BR76-69-270B-06
	L BR77-69-320B-06
Gray/Taupe	R BR76-69-270A-39
	L BR76-69-320A-39
From 2-1-94	
Gray	R BR76-69-270B-06
	L BR77-69-320B-06
Gray/Taupe	R BR76-69-270A-39
	L BR77-69-320B-36
w/o Mirror To 2-1-94	
Gray	R BR74-69-270B-06
	L BR76-69-320B-06
Gray/Taupe	R BR74-69-270A-39
	L BR76-69-320A-39
From 2-1-94	
Gray	R BR74-69-270B-06
	L BR76-69-320B-06
Gray/Taupe	R BR74-69-270B-36
	L BR76-69-320B-36

**NOZZLE, SPRAY** R/L N.A.

## COWL & DASH

035-01332

1 Grille Assy, Cowl	BR70-50-790E
2 Protector, Grille	B455-50-794A
3 Cap (5)	B455-50-796A
*Included w/Cowl Grille Assy	
4 Plate, Baffle	R BR70-56-191D
	L BR70-56-192B
5 Panel, Cowl Front	B455-70-62YD
6 Panel, Dash Upper	BR70-53-510J
7 Panel, Dash Lower	
FWD	BR70-53-400G
AWD	BA1C-53-400B

## SPEAKER, RADIO-SEE FRONT DOOR SECTION

## CENTER CONSOLE

035-01281

### Console Assy, Front

1 Man Trans	
w/Cup Holder	B457-64-320D-48
w/o Cup Holder	B455-64-320-48
2 Auto Trans	
w/Cup Holder	B458-64-320D-48
w/o Cup Holder	B455-64-321-48
3 Box, Console (a)	B457-64-360C-48
*Blue listed, Order by Application	
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black	
6 Boot, Change (a)	B455-64-330
7 Bracket, Front Console (a)	
w/Cup Holder	B457-64-31X
w/o Cup Holder	
Man Trans	BW3F-64-316
Auto Trans	R B457-64-31Y
	L B456-64-316
*Included w/Front Console Assy	
8 Console, Rear	BR70-64-420B-48
9 Ashtray	BR70-64-660A-48
*Blue listed, Order by Application	
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black	

## WIPER SYSTEM

035-01279

1 Blade Assy, Wiper	R NC11-67-330-9U
	L BR70-67-330C
Insert, Wiper	R B460-67-333
	L D040-67-333-9U
*Included w/Wiper Blade Assy	
2 Arm, Wiper	R BR71-67-321
	L BR70-67-321
3 Cover, Wiper Arm	R/L LA01-67-395C
4 Link Assy, Wiper	BR71-67-360
5 Arm, Wiper Link	R BR70-67-362
	L BS34-67-361
6 Shaft, Drive	R/L BR71-67-363-4
*Included w/Wiper Link Assy	
7 Motor, Wiper	
Std Duty	BR70-67-340
Hvy Duty	BR71-67-340
8 Reservoir & Pump Assy	
FWD	
w/Level Switch	BR72-67-480C
w/o Level Switch	B455-67-480A
AWD	BR70-67-480B
9 Tank, Washer	
FWD	
w/Level Switch	BR72-67-481
w/o Level Switch	B455-67-481A
AWD	BR70-67-481A
10 Cap, Tank	B455-67-483
11 Switch, Level	BR72-67-488
12 Pump, Washer	S084-76-672
*Included w/Reservoir & Pump Assy	

## INSTRUMENT PANEL

035-02090

1 Panel, Instrument	BR70-60-350D-48
2 Garnish, Upper	BR70-60-720B-48
3 Pad Assy, Lower	
To 11-1-92	R BR70-64-260-48
	L BR70-64-280-48
From 11-1-92	R BR70-64-260-48
	L BR70-64-280-48
4 Louver, Lower Pad (a)	FB01-64-850
*Blue listed, Order by Application	
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black	
(a) Included w/Right Lower Pad Assy	
5 Crossmember, Inst Panel	BR70-60-420C
6 Reint, Inst Panel	BR70-60-430
7 Protector, Knee	
FWD	BR70-60-K80A
AWD	
To 5-8-90	BR70-60-K80A
From 5-8-90	BR70-60-K80A
8 Cover, Under	BR70-64-520A
9 Brkt, Inst Panel	R BR70-60-56X
	L BR70-60-56X
10 Frame, Upper	BR70-60-610
11 Frame, Lower	BR70-60-620
12 Panel Assy, Center Lower	BR70-64-270-48
*Blue listed, Order by Application	
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black	
13 Lens, Ashtray (a)	BR70-55-215
(a) Included w/Lower Center Panel Assy	
14 Glove Box Assy	BR70-64-030A-48
15 Glove Box, Lid (a)	BR70-64-041-48
*Blue listed, Order by Application	
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black	
16 Glove Box (a)	BR70-64-161A
Hinge, Glove Box (a)	R/L B455-64-071-2
(a) Included w/Glove Box Assy	
17 Cover, Glove Box Radio Assy	BR70-64-110
	0000-81-601B
*Order by Application	

## ROCKER/PILLARS/FLOOR

### ROCKER/PILLARS HATCHBACK

035-02475

1 Pillar Assy, Hinge	
Outer	R BR93-70-210
	L BR93-71-210
2 Panel Assy, Cowl Side	R BR70-70-020
	L B455-71-020
3 Bracket, Fender (a)	R/L B092-70-070A
*Included w/Outer Hinge Pillar Assy	
(a) Included w/Cowl Side Panel Assy	
4 Moulding Set, Pillar	R B467-50-8B0A
	L B467-50-8C0A
5 Moulding, Upper End	R B467-50-8B4
	L B467-50-8C4
6 Protector, Midg Outer	R B467-50-8B3A
	L B467-50-8C3A
7 Protector, Midg Inner	R/L B467-50-8B2B
*Included w/Pillar Moulding Set	
8 Panel, Cowl Trim (a)	R BR70-68-370A-32
	L BR70-68-390B-32
(a) Gray/Taupe listed, Order by Application	

madpl1\_g01\_

Procedure Explanation Pages Must Be Used with the Above Text for an Accurate Damage Report.  
Comments or suggestions? Need assistance? Call 1-800-854-7030 or 858-578-6550. Ext. 8220. Fax 1-888-256-7969 or 858-549-0629.

51



# MAZDA 323/PROTEGE 1990-94

ROCKER/PILLARS/FLOOR Cont'd	
<b>ROCKER/PILLARS HATCHBACK Cont'd</b>	
Mldg, Inside Garnish	
9 USA-See Windshield Section	
10 Canada-See Quarter Panel Section	
	19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black
11 Pillar, Hinge Inner	R B467-70-24X L B467-71-24X
12 Panel, Rocker Outer	R B467-70-270C L B467-71-270C

ROCKER/PILLARS SEDAN	
-------------------------	--

035-02476

**Pillar Assy, Hinge**  
1 Outer R BR70-70-210  
L BR70-71-210

**2 Panel Assy, Cowl Side** R BR70-70-020  
L B455-71-020

**3 Bracket, Fender (a)** R/L B092-70-070A  
\*Included w/Outer Hinge Pillar Assy  
(a) Included w/Cowl Side Panel Assy

**4 Panel, Cowl Trim (b)** R BR70-68-370A-48  
L BR70-68-390B-48  
(b) Blue listed, Order by Application  
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black

**5 Pillar, Hinge Inner** R B455-70-24X  
L B455-71-24X

**Pillar, Center Outer-See Quarter Panel Section**

**6 Pillar, Center Inner** R B455-70-080C  
L B455-71-080C

**Mldg, Inside Garnish**  
Upper

7 USA-See Windshield Section

8 Canada R/L N.A.

9 Lower R BR70-68-220A-32  
L BR70-68-230A-32  
\*Gray/Taupe listed, Order by Application  
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black

**10 Panel, Rocker Outer** R B455-70-270B  
L B455-71-270B

**FLOOR**

035-01284

**1 Panel, Rocker Inner** R BR70-53-950D  
L BR71-54-950

**Plate, Scuff**  
Hatchback R B499-68-710B-48  
L B499-68-720B-48


Sedan  
Front R B455-68-710B-48  
L B455-68-720B-48  
Rear R B455-68-730C-48  
L B455-68-740C-48  
\*Blue listed, Order by Application  
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black

**2 Pan, Front Floor**  
FWD BR70-53-600D  
AWD BA1C-53-600B

**3 Member, Front Side Rear**

FWD	R BR70-53-660C L BR70-54-660B
AWD	R/L BA1C-53-660C

## SEAT



**1 Seat Assy, Front**  
Hatchback  
Base Model R BB7A-57-100B-65  
L BB7A-57-150B-65  
DX Model R BB7H-57-100B-65  
L BB7H-57-150B-65

SE Model  
w/25th Anniversary Pkg  
Right BC0D-57-100A-64  
Left BC0C-57-150A-64  
w/o 25th Anniversary Pkg  
Right BB7H-57-100B-65  
Left BB7H-57-150B-65  
LX R BC0D-57-100A-64  
L BC0C-57-150A-64

Sedan  
DX, SE Model R BB7C-57-100-65  
L BB7C-57-150E-65  
GT Model R BB7R-57-100D-64  
L BB7R-57-150D-64  
LX Model R BB7D-57-100E-64  
L BB7D-57-150-64  
\*Off Black listed, Order by Application  
32 Gray/Taupe; 48 Blue; 64, 65 Off Black

**2 Adjuster, Seat (a)**  
Passenger Side R BR72-88-102A  
L BR95-88-103B  
Driver Side R BR72-88-152B  
L BR72-88-153A  
R/L B455-88-026

**3 Wire (a)**

**4 Cushion, Front Seat (a)**  
Hatchback  
Base Model R BB7A-88-110-65  
L BB7A-88-160-65  
DX Model R BB7H-88-110-65  
L BB7H-88-160-65

SE Model  
w/25th Anniversary Pkg  
Right BC0C-88-110-64  
Left BB7E-88-160-64  
w/o 25th Anniversary Pkg  
Right BB7H-88-110-65  
Left BB7H-88-160-65  
LX Model R/L N.A.

Sedan  
DX, SE Model R BB7C-88-110-65  
L BB7C-88-160-65  
GT Model R BB7R-88-110-64  
L BB7R-88-160-64  
LX Model R BB7D-88-110-64  
L BB7D-88-160-64

**5 Back Assy, Front Seat (a)**  
Hatchback  
Base Model R BB7A-88-130A-65  
L BB7A-88-180A-65  
DX Model R BB7H-88-130A-65  
L BB7H-88-180A-65

SE Model  
w/25th Anniversary Pkg  
Right BC0D-88-130A-64  
Left BC0C-88-180A-64  
w/o 25th Anniversary Pkg  
Right BB7H-88-130A-65  
Left BB7H-88-180A-65  
LX Model R/L N.A.

Sedan  
DX, SE Model R BB7C-88-130A-65  
L BB7C-88-180A-65  
GT Model R BB7R-88-130B-64  
L BB7R-88-180B-64  
LX Model R BB7D-88-130C-64  
L BB7D-88-180-64  
\*Off Black listed, Order by Application  
32 Gray/Taupe; 48 Blue; 64, 65 Off Black

**6 Adjuster, Recline (a) (b)**  
Hatchback R BR93-88-101  
L BR70-88-151  
Sedan R BR70-88-101  
L BR70-88-151  
(b) Included w/Front Seat Back Assy

**7 Cover, Adjuster (a)** R BR70-88-127B-64  
L BR70-88-177B-64

**8 Knob, Adjuster (a)** R B001-88-081-65  
L B001-88-091-65

**9 Headrest (a)**  
Hatchback  
Base, DX Model R/L BB7A-88-140-65  
LX, SE Model R/L BB7H-88-140-65

Sedan  
DX, SE Model R/L B618-88-140-65  
GT Model R/L BR73-88-140B-64  
LX Model R/L BB7E-88-140-64  
\*Off Black listed, Order by Application  
32 Gray/Taupe; 48 Blue; 64, 65 Off Black  
(a) Included w/Front Seat Assy


**10 Cover, Adjuster**  
Passenger Side R B455-57-051B  
L B455-57-052C  
Driver Side R B455-57-053C  
L B455-57-054B

**11 Bracket, Front Seat** R B455-57-580A  
L B455-57-590A

## REAR SEAT

## SEAT BELTS

### FRONT USA



**1 Belt, Outer Seat**  
Hatchback R BR93-57-930G  
L BR70-57-990H  
Sedan R BR70-57-930H  
L BR70-57-990H

**2 Retractor, Center**  
Hatchback  
Blue BR70-57-620A-48  
Gray/Taupe BR70-57-620A-32  
Off Black BR70-57-620A-65

Sedan  
Blue BR70-57-920F-48  
Gray/Taupe BR70-57-920F-32  
Off Black BR70-57-920F-65

**3 Belt, Lap**  
Hatchback  
Blue R BR70-57-940D-48  
L BR70-57-980D-48  
Gray/Taupe R BR70-57-940D-32  
L BR70-57-980D-32  
Off Black R BR70-57-940D-65  
L BR70-57-980D-65

Sedan  
Blue R BR70-57-940C-48  
L BR70-57-980D-48  
Gray/Taupe R BR70-57-940C-32  
L BR70-57-980D-32  
Off Black R BR70-57-940C-65  
L BR70-57-980D-65

**4 Buckle, Belt**  
Blue R BR70-57-620A-48  
L BR70-57-680A-48  
Gray Taupe R BR70-57-620A-32  
L BR70-57-680A-32  
Off Black R BR70-57-620A-65  
L BR70-57-680A-65  
\*Order by Application

**5 Bracket, Seat Belt** R/L BR70-57-925A

**6 Handle, Emergency** FC01-57-999A

**7 Control Unit, Passive** BR70-67-780D

### FRONT CANADA

Illustration Located in Next Column

**Belt, Seat**


# MAZDA 323/PROTEGE 1990-94

## FRONT DOOR

### SHEET METAL

<b>Shell Assy, Door</b>	
Hatchback	R BR93-58-020T L BR93-59-020T
Sedan	R BS06-58-020K L BS06-59-020K
<b>Panel, Door Repair†</b>	
Hatchback	R B468-58-030C L B468-59-030C
Sedan	R B455-58-031B L B455-59-031B
†Included w/Door Shell Assy	

### EXTERIOR TRIM



<b>1 Moulding, Belt</b>	
Hatchback	R B468-58-640A L B468-59-650A
Sedan	R B456-58-640 L B456-59-650
<b>2 Moulding, Side Adhesive</b>	
Hatchback	R B4Y7-50-682 L B4Y7-50-692
Sedan	R B4Y5-50-682 L B4Y5-50-692
Canada	R/L N.A.
<b>Mirror, Rear View</b>	
<b>3 Manual</b>	
Hatchback	R BR94-69-110B L BR94-69-170B
Sedan	R BR72-69-110B L BR72-69-170B
<b>4 Power†</b>	
Hatchback	R BR96-69-120C-UF L BR96-69-180C-UF
To 4-1-93	R BR96-69-120C-UF L BR96-69-180C-UF
From 4-1-93	R BR96-69-180C-UF L BR96-69-180C-UF
Sedan	R BR74-69-120C-UF L BR74-69-180C-UF


†Clear White listed. Order by Application  
 DV Bay Blue; DX Honey Blue;  
 E9 Deep Purple; FZ Herbie Green;  
 J4 Passion Rose; PZ Brilliant Black;  
 SQ Blaze Red; SS Coral Red  
 UF Clear White; Z1 Bluish Green M;  
 IH Steel Gray MC; IS Niagara Silver MC;  
 3L Silver Stone Met; 4R Passion Yellow Mica  
 4Z Silent Silver; 5D Harbor Blue M; 5S Neat Green MC;  
 6C Mighty Gray; 6L Graceful Red MC;  
 6M Elegant Beige; 6N Current Blue MC;  
 6S Excess Green; 6V Raspberry Metallic  
 6W Laguna Blue M; 6Y Sea Mist M

<b>5 Garnish, Mirror</b>	
Manual†	R B472-69-111B L B472-69-171B
Power	R B471-69-111B L B471-69-171B
<b>Knob, Mirror Door†</b>	
Outer	R/L D062-69-1B6
Inner	R/L D062-69-1B5
†Order by Application	
<b>8 Wire, Remote Control</b>	R/L B463-69-108

### INTERIOR TRIM


Illustration Located in Next Column

<b>1 Panel Assy, Trim†</b>	
Hatchback	R BR93-68-420E-32 L BR93-68-450E-32
Base Model	R BR93-68-420E-65 L BR93-68-450E-65
Gray Taupe	R BR93-68-420E-65 L BR93-68-450E-65
Off Black	R BR93-68-420E-65 L BR93-68-450E-65
SE Model	
w/25th Anniversary Pkg	R BC3H-68-420-32 L BC3H-68-450D-32
Gray/Taupe	R BR93-68-420E-65 L BR93-68-450E-65




Off Black	R BC3H-68-420-65 L BC3H-68-450-65
w/o 25th Anniversary Pkg	
Gray/Taupe	R BR94-68-420F-32 L BR94-68-450F-32
Off Black	R BR94-68-420F-65 L BR94-68-450F-65
Sedan	
GT Model	R BB7F-68-420J-65 L BB7F-68-450H-65
Off Black	R BB7F-68-420J-65 L BB7F-68-450H-65
SE Model	
Gray/Taupe	R BR71-68-420E-32 L BR71-68-450E-32
Off Black	R BR71-68-420E-65 L BR71-68-450E-65
LX Model	
Blue	R BB1C-68-420H-48 L BB1C-68-450K-48
Gray/Taupe	R BC3M-68-420C-32 L BC3M-68-450C-32
Off Black	R BR75-68-420C-65 L BR75-68-450C-65
†Order by Application	
32 Gray/Taupe; 48 Blue; 65 Off Black	
<b>2 Weatherstrip, Inner (b)</b>	
Hatchback	R B467-58-821 L B467-59-821
Sedan	R B455-58-821 L B455-59-821
Canada	R/L B101-68-421-48
<b>3 Cover, Door Lock† (b)</b>	
<b>4 Pocket, Door† (b)</b>	
Hatchback	R B471-68-4C1-48 L B471-68-4N1-48
Canada	R B455-68-4C1A-48 L B455-68-4N1A-48
USA	R B455-68-4C1A-48 L B455-68-4N1A-48
Sedan	
SE Model	R B455-68-4C1A-48 L B455-68-4N1A-48
GT, LX Model	R B461-68-4C1-48 L B461-68-4N1-48
<b>5 Grip, Assist† (b)</b>	
Base, SE Model	R B455-69-460B L B455-69-470B
GT, LX Model	R B461-69-461A L B461-69-471A
<b>6 Grille, Speaker† (b)</b>	
Blue	R/L BR70-68-4H0A-48
Gray/Taupe	R/L BR70-68-4H0A-32
Off Black	R/L BR70-68-4H0A-65
†Blue listed. Order by Application	
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black	
(b) Included w/Trim Panel Assy	
<b>Speaker, Radio</b>	
R/L	BR73-66-96X
<b>7 Armrest†</b>	
R	UB40-69-370-48
L	UB40-69-390-48
†Blue listed. Order by Application	
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black	

### HARDWARE




<b>1 Latch</b>	
Hatchback	R BR93-58-310A L BR93-59-310A
Manual	R BR93-58-310B L BR93-59-310C
Power	R BR93-58-310B L BR93-59-310C
Sedan	




<b>1 Retractor Side</b>	
Blue	R/L N.A.
Gray/Taupe	R/L N.A.
Off Black	R/L N.A.
<b>2 Buckle Side</b>	
Blue	R/L N.A.
Gray/Taupe	R/L N.A.
Off Black	R/L N.A.
<b>3 Plate, Seat Belt</b>	
	R/L N.A.

### REAR HATCHBACK



<b>1 Belt, Seat Outer</b>	
Blue	R BR93-57-710B-48 L BR93-57-770B-48
Gray/Taupe	R BR93-57-710B-32 L BR93-57-770B-32
Off Black	R BR93-57-710B-65 L BR93-57-770B-65
<b>2 Belt, Seat Center</b>	
Blue	BR70-57-740A-48
Gray/Taupe	BR70-57-740A-32
Off Black	BR70-57-740A-65


### REAR SEDAN



<b>1 Belt, Seat Outer</b>	
Blue	R BR70-57-710B-48 L BR70-57-770B-48
Gray/Taupe	R BR70-57-710B-32 L BR70-57-770B-32
Off Black	R BR70-57-710B-65 L BR70-57-770B-65
<b>2 Belt, Seat Center</b>	
Blue	BR70-57-740A-48
Gray/Taupe	BR70-57-740A-32
Off Black	BR70-57-740A-65
<b>3 Cover, Anchor</b>	
Blue	R/L BR70-57-631-48
Gray/Taupe	R/L BR70-57-631-32
Off Black	R/L BR70-57-631-65


# MAZDA 323/PROTEGE 1990-94


FRONT DOOR Cont'd	
<b>HARDWARE Cont'd</b>	
Manual	R BR70-58-310A L BR70-59-310A
Power	R BR71-58-310B L BR71-59-310B
2 Striker	R/L B092-58-361A
3 Knob Assy, Door Lock†	
Hatchback	R B467-58-390B-48 L B467-59-390A-48
Sedan	R B455-58-390B-48 L B455-59-390B-48
4 Knob, Door Lock† (a)	R/L B455-58-316B-48
†Blue listed, Order by Application 19 Red; 32 Gray Taupe; 48 Blue; 65 Off Black	
(a) Included w/Door Lock Knob Assy	
5 Control, Lock	
Hatchback	90-91 R/L BF67-58-350 92-95 R/L BR94-58-350
Sedan	90 R/L BF67-58-350 91-95 R/L BR71-58-350B
Cylinder w/Key	R BR70-76-210B L BR70-76-220B
6 Handle, Outside	
Black	R B455-58-410E L B455-59-410E
Body Color†	R B459-72-410D-SQ L B459-73-410D-SQ
†Blaze Red listed, Order by Application DV Bay Blue; DX Honey Blue; E9 Deep Purple; FZ Herbie Green; GU Shade Green; PZ Brilliant Black; SQ Blaze Red; SS Coral Red; UF Clear White; Z1 Bluish Green M; 1H Steel Gray MC; 1S Niagara Silver MC; 3L Silver Stone M; 4R Passion Yellow Mica; 4Z Silent Silver; 5D Harbor Blue M; 5L Whisper Green; 5S Neat Green; 6C Mighty Gray; 6L Graceful Red; 6M Elegant Beige; 6N Current Blue MC; 6S Exceed Green M; 6V Raspberry Metallic; 6W Laguna Blue M	
7 Handle, Inside	R/L B455-58-330B-00
8 Hinge, Upper	R B455-59-240A L B455-58-240A
9 Hinge, Lower	R B455-58-240A L B455-59-240A
10 Shim, Hinge (2/Side)	R/L B092-58-201A
11 Check, Door	
Hatchback	R/L B499-58-270B
Sedan	To 10-1-94 R/L B455-58-270B From 10-1-94 R/L B607-58-270
Weatherstrip, Door	
Hatchback	R BS20-58-760E L BS20-59-760E
Sedan	R B455-58-760F L B455-59-760F
Welt, Seaming†	
Hatchback	R B467-68-911A-48 L B467-68-912A-48
Sedan	R B455-68-911C-48 L B455-68-912C-48
†Blue listed, Order by Application 19 Red; 23 Gray Taupe; 48 Blue; 65 Off Black	


GLASS & PARTS	
	
1 Glass, Front Door	
Mazda	
Hatchback	R B467-58-511B L B467-59-511B
Clear	R B469-58-511B L B469-59-511B
Blue Tint	

Sedan		R B455-58-511 L B455-59-511
Clear		R B457-58-511 L B457-59-511
Blue Tint		
2 Channel Assy, Glass		R B467-58-60XA L B467-59-60XA
Hatchback		R B455-58-605 L B455-59-605
Sedan		R B455-58-605 L B455-59-605
3 Adjuster, Glass†	R/L BS06-58-606	
†Included w/Glass Channel Assy		
4 Regulator, Manual		R B455-58-560A L B455-59-560A
5 Handle, Regulator		R/L B092-58-580-00 From 8-1-93 R/L S084-58-580A-00
6 Escutcheon, Handle	R/L B092-58-863A	
7 Regulator Assy, Power		R B456-58-560C L B456-59-560C
8 Motor, Regulator†		R B456-59-560C L B500-59-58XA
†Included w/Power Regulator Assy		

REAR DOOR	
SHEET METAL	
Shell Assy, Door	R BR70-72-020W L BR70-73-020W
Panel, Door Repair†	R B455-72-031B L B455-73-031B
†Included w/Door Shell Assy	

EXTERIOR TRIM	
	
1 Moulding, Belt	R B456-50-660A L B456-50-670A
2 Moulding, Side	
Adhesive	
USA	R B4Y5-50-683 L B4Y5-50-693
Canada	R/L N.A.

INTERIOR TRIM	
	
1 Panel Assy, Trim†	
SE Model	
Gray/Taupe	R BR71-68-520B-32 L BR71-68-550B-32
Off Black	R BR71-68-520B-65 L BR71-68-550B-65
GT Model	
Off Black	R BB7F-68-520B-65 L BB7F-68-550B-65
LX Model	
Blue	R B621-68-520D-48 L B621-68-550C-48
Gray/Taupe	R B621-68-520C-32 L B621-68-550C-32
Off Black	R B621-68-520D-65 L B621-68-550E-65
†Order by Application 32 Gray Taupe; 48 Blue; 65 Off Black	
2 W/Strip, Inner (a)	R B455-72-821 L B455-73-821
3 Vessel, Inner Lock† (a)	R/L B101-68-421-48
4 Handle, Pull† (a)	
LX Model	R/L B461-68-D71A-48
(a) Included w/Trim Panel Assy	
5 Armrest†	
SE Model	R UB40-69-370-48 L UB40-69-390-48
†Blue listed, Order by Application 19 Red; 32 Gray Taupe; 48 Blue; 65 Off Black	

6 Bracket, Pull Handle	
LX Model	R/L B110-68-525
HARDWARE	
	
1 Latch Assy, Door	
Manual	R B455-72-310B L B455-73-310B
Power	R B456-72-310C L B456-73-310B
2 Striker-See Quarter Panel Section	
3 Knob Assy, Door Lock†	R/L B455-72-390C-48
4 Knob, Door Lock† (a)	R/L B455-58-316B-48
†Blue listed, Order by Application (a) Included w/Door Lock Knob Assy 19 Red; 32 Gray Taupe; 48 Blue; 65 Off Black	
5 Control, Lock	R BTAC-72-350 L B456-73-350B
6 Handle, Outside	
Black	R B455-72-410E L B455-73-410E
Body Color†	R B459-72-410D-SQ L B459-73-410D-SQ
†Blaze Red listed, Order by Application DV Bay Blue; DX Honey Blue; E9 Deep Purple; FZ Herbie Green; GU Shade Green; PZ Brilliant Black; SQ Blaze Red; SS Coral Red; UF Clear White; Z1 Bluish Green M; 1H Steel Gray MC; 1S Niagara Silver MC; 3L Silver Stone M; 4R Passion Yellow Mica; 4Z Silent Silver; 5D Harbor Blue M; 5L Whisper Green; 5S Neat Green; 6C Mighty Gray; 6L Graceful Red; 6M Elegant Beige; 6N Current Blue MC; 6S Exceed Green M; 6V Raspberry Metallic; 6W Laguna Blue M	
7 Handle, Inside	R/L B455-58-330B-00
8 Hinge, Upper	R B455-72-210A L B455-73-210A
9 Hinge, Lower	R B455-72-240A L B455-73-240A
10 Shim, Hinge Upper	R/L B455-72-231A
11 Shim, Hinge Lower	R/L B092-72-231A
12 Check, Door	
To 10-1-94	R/L B455-72-270B
From 10-1-94	R/L B607-72-270
13 Stopper, Bumper Upper	R BR70-72-916C L BR70-73-916C
14 Stopper, Bumper Lower	R BR70-72-915C L BR70-73-915C
W/Strip, Door	R B455-72-760G L B455-73-760G
Welt, Seaming†	R B455-68-913A-48 L B455-68-914A-48
†Blue listed, Order by Application 19 Red; 32 Gray Taupe; 48 Blue; 65 Off Black	

GLASS & PARTS	
<i>Illustration Located in Next Column</i>	
1 Glass, Rear Door	
Mazda	
Clear	R B455-72-511A L B455-73-511A
Blue Tint	R B457-72-511A L B457-73-511A
2 Glass, Rear Vent	
Mazda	
Clear	R B455-72-661 L B455-73-661
Blue Tint	R B457-72-661 L B457-73-661
3 Run, Upper	R B455-72-605 L B455-73-605
4 Bar, Division	R B455-72-602C L B455-73-602C
Protector, Bar	

# MAZDA 323/PROTEGE 1990-94

035-01292

5 Outer	R B455-72-608
	L B455-73-608
6 Inner	R B456-72-608
	L B456-73-608
7 W/Strip, Vent Glass	R B455-72-651A
	L B455-73-651A
8 Bracket, Lift	R/L B268-72-520
9 Seal, Bracket (2/Side)	R/L S001-58-502
10 Regulator, Manual	R B455-72-560C
	L B455-73-560C
11 Handle, Regulator	R/L B092-58-580-00
To 8-2-93	R/L S084-58-580A-00
12 Escutcheon, Handle	R/L B092-58-863A
13 Regulator Assy, Power	R B457-72-58X
	L B456-73-58X
14 Motor, Regulator¶	R B457-72-58X
To 8-1-91	L B456-73-58X
From 8-1-91	R B457-72-58X
	L B456-73-58X
15 Base, Regulator¶	R B456-72-59X
	L B456-73-58X

¶Included w/Power Regulator Assy

## ROOF SHEET METAL

035-01293

1 Panel, Roof	w/Sunroof B4X2-70-600
	w/o Sunroof Hatchback B4X7-70-600A
	Sedan B4Y5-70-600
Antenna, Radio	0000-81-0730
Cover, Antenna Opng	BR71-66-9A0
2 Moulding, Roof	Hatchback R B4Y7-50-9H0A
	L B4Y7-50-9L0A
	Sedan R BW5B-50-9H0A
	L BW5B-50-9L0A
3 Panel, Front Header	Hatchback B467-70-640A
	Sedan B455-70-640A
4 Panel, Rear Header	Hatchback B467-70-700B
	Sedan B455-70-701
5 Bow, Reinforcement	w/o Sunroof Hatchback B467-70-661A
	Sedan B455-70-661B
6 Reinf, Sunroof	U012-70-630
7 Bracket, Sunroof	R B462-70-620A
	L B462-71-620A

8 Rail, Roof Inner	R B467-70-050
Hatchback	L B467-71-050
Sedan	R B455-70-050B
	L B455-71-050B

## INTERIOR TRIM HATCHBACK

035-02091

1 Headliner Assy	To 8-2-93 Gray BR94-68-030C-05
	Gray/Taupe BR94-68-030C-34
From 8-2-93	Gray BR94-68-030C-05
	Gray/Taupe BR94-68-030C-05
2 Insulator, Roof¶	B481-68-022
¶Included w/Headliner Assy	
3 Mldg, Inside Garnish	Gray B467-68-140-06
	Gray/Taupe B467-68-140-35

## INTERIOR TRIM SEDAN

035-02092

1 Headliner	w/Sunroof Gray BR72-68-030C-05
	Gray/Taupe BR72-68-030C-34
w/o Sunroof	To 8-2-93 Gray B456-68-030F-08
	Gray/Taupe BR71-68-030F-34
2 Bracket, Headliner	R BR70-68-06XB
	L BR70-68-06YB
3 Mldg, Inside Garnish	Gray B455-68-140B-06
	Gray/Taupe B455-68-140B-35

## OVERHEAD CONSOLE

035-01296

1 Console Assy, Overhead	Gray B462-69-970-06
	Gray/Taupe B462-69-970-35
2 Cover, Console¶	Gray B462-69-972-06
	Gray/Taupe B462-69-972-35
¶Included w/Overhead Console Assy	

## SUNROOF

035-02093

035-02094

1 Panel, Steel Sliding	BR71-69-810A
2 W/Strip, Steel Panel	BR71-69-825A
3 Trim, Steel Sunroof¶	BR71-69-960-06
¶Gray listed, Order by Application	
	06 Gray; 39 Gray/Taupe
4 Panel, Glass Sliding	B462-69-810
5 Shade, Glass Sunroof	Gray B462-69-891-06
	Gray/Taupe B462-69-891-39
6 Welt, Seaming	Gray B096-69-915A-06
	Gray/Taupe B096-69-915A-35
7 Rail, Drip	B462-69-867
8 Panel, Lower Cover, Lower Panel	Side R B098-69-861
	L B098-69-862-00
9 Side	B098-69-863A
10 Center	R B096-69-839
11 Guide, Rail Front	L B096-69-841
12 Guide, Rail Side Front	Steel Sunroof R B096-69-832A
	L B096-69-833A
	Glass Sunroof R B098-69-832A
	L B098-69-833A
13 Guide, Rail Side Rear	Steel Sunroof R/L BR71-69-864-5
	Glass Sunroof R/L B462-69-864-5
14 Cover, Guide Rail	Steel Sunroof R B096-69-834A
	L B096-69-835A
	Glass Sunroof R B098-69-834B
	L B098-69-835B
15 Plate Set	R B462-69-855
	L B462-69-856
16 Connector, Link	R/L B096-69-867
17 Stopper, Sliding Panel	R/L B096-69-852
18 Frame, Sliding Roof	B462-69-840
19 Motor, Sliding Roof	B462-69-848A
20 Bracket, Drive Unit	B462-69-861
21 Deflector	Steel Sunroof BR71-69-881
	Glass Sunroof B462-69-881
22 Link, Deflector	R B096-69-846B
	L B096-69-847B


## BACK WINDOW

Illustration Located in Next Column

1 Glass, Back Window	Mazda
	USA Clear B455-63-931B
	Blue Tint B457-63-930B
	Canada N.A.
2 Spacer, Glass	R/L GJ51-50-891
3 Dam, Back Window	B456-50-899A
4 Mldg, Reveal Upper	8AB1-50-811
5 Moulding Assy, Reveal Side	R 8AB1-50-812
	L 8AB1-50-813


# MAZDA 323/PROTEGE 1990-94

## BACK WINDOW Cont'd



- 6 Joint, Upper¶ R/L B455-50-615-6
  - 7 Protector, Mldg¶ (a) R B455-50-6H6  
L B455-50-6H7
  - 8 Protector, Center¶ (a) B455-50-6H3
  - 9 Joint, Lower¶ (a) B455-50-617
- ¶Included w/Side Reveal Moulding Assy  
 (a) Included w/Right Side Reveal Moulding Assy

## QUARTER PANEL SHEET METAL HATCHBACK





- 1 Panel, Quarter Outer R B467-70-401B  
L B4X7-71-400B
  - Door, Fuel w/Door Opener B468-42-410B  
w/o Door Opener B467-42-410B
  - Cylinder & Key BR70-76-240B
  - 2 Panel Assy, Inner R BR93-70-100  
L BR93-71-100
  - 3 Panel, Inner¶ R BR93-70-10X  
L BR93-71-10X
  - 4 Panel, Wheelhouse¶ R B455-70-150H  
L B607-71-150
  - 5 Plate, Joint Front¶ R B455-70-152  
L B455-71-152
  - 6 Plate, Joint Rear¶ R/L B467-70-153
  - 7 Pillar, Rear Inner¶ R B467-70-113  
L B467-71-113
- ¶Included w/Inner Panel Assy
- 8 Reinf, Lock Pillar R B4X7-70-420C  
L B4X7-71-420C
  - 9 Plate, Lock Pillar R BW0G-70-470A  
L BW0G-71-470A
  - Striker, Latch R/L B092-58-361A

## SHEET METAL SEDAN


Illustration Located in Next Column

- 1 Panel Assy, Quarter USA-Serviced by Components  
Canada R N.A.  
L N.A.
  - 2 Panel, Quarter¶ R B4Y5-70-41XD  
L B4Y5-71-41XD
  - 3 Panel, Rocker Outer¶ R B4Y5-70-27XF  
L B4Y5-71-27XF
  - 4 Pillar, Center Outer¶ R B4Y5-70-350E  
L B4Y5-71-350E
- ¶Included w/Quarter Panel Assy
- 5 Door, Fuel w/Door Opener B456-42-410C



- 6 w/o Door Opener B455-42-410C  
Cylinder & Key BR70-76-240B
- 7 Panel Assy, Inner FWD R BR70-70-110  
L BR70-71-110  
AWD R BA1C-70-110  
L BA1C-71-110  
R BR70-70-11XA  
L BR70-71-11XA
- 8 Panel, Inner¶ R B455-70-150H  
L B607-71-150  
AWD R B528-70-150H  
L B528-71-150H  
R B455-70-152  
L B455-71-152
- 9 Panel, Wheelhouse¶ FWD R B455-70-180E  
L B455-71-180E
- 10 Bracket, Wheelhouse¶ R B455-70-180E  
L B455-71-180E
- 11 Plate Assy, Joint¶ ¶Included w/Inner Panel Assy
- 12 Panel, Package Tray B455-70-500E
- 13 Reinf, Center Pillar R B4Y5-70-420  
L B4Y5-71-420
- 14 Plate, Center Pillar R BR70-70-470B  
L BR70-71-470B
- 15 Pillar, Center Inner-See Rocker/Pillars/Floor Section
- 16 Striker, Latch R/L B092-58-361A

## EXTERIOR TRIM HATCHBACK




- 1 Guard, Stone R BR93-50-481  
L BR93-50-491
- Stripe Tape-See Stripe Tape Section
- 2 Moulding, Side Adhesive R/L B4Y7-50-693

## INTERIOR TRIM HATCHBACK


Illustration Located in Next Column

- Mldg, Inside Garnish
- 1 USA-See Windshield Section
- 2 Canada Gray R/L N.A.  
Gray/Taupe R/L N.A.
- 3 Trim, Pillar Rear Gray R B467-68-250B-06  
L B467-68-260B-06  
Gray/Taupe R B467-68-250B-35



- 4 Panel Assy, Trim¶ Base Model L B467-68-260B-35  
R BR93-68-520E-65  
L BR93-68-550E-65
- SE Model w/25th Anniversary Pkg Right BC3G-68-520-65  
Left BC3G-68-550-65
- w/o 25th Anniversary Pkg Right BR94-68-520E-65  
Left BR94-68-550E-65
- ¶Off Black listed, Order by Application  
32 Gray/Taupe; 48 Blue; 65 Off Black
- 5 Grille Assy, Speaker¶ (a) Blue R B467-68-5H0A-48  
L B467-68-5T0A-48  
Gray/Taupe R B467-68-5H0B-32  
L B467-68-5T0B-32  
Off Black R B467-68-5H0A-65  
L B467-68-5T0A-65
- ¶Order by Application
- 6 Spring, Center Panel (a) (b) R/L B092-55-257  
(b) Included w/Speaker Grille Assy
- 7 Cover, Hole Front¶ (a) R BR93-68-529-48  
L BR93-68-559-48
- 8 Cover, Hole Rear¶ (a) R/L B499-68-893-48  
¶Blue listed, Order by Application  
32 Gray/Taupe; 48 Blue; 65 Off Black  
(a) Included w/Trim Panel Assy
- 9 Speaker, Radio (c) R/L 0000-81-089A-01  
(c) Order by Application
- 10 Trim, Trunk Side¶ R B467-68-850B-48  
L B467-68-870B-48
- ¶Blue listed, Order by Application  
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black
- 11 Bracket, Lid R B467-68-8HX  
L B467-68-8HY
- 12 Vessel, Belt¶ R BR93-68-3B1-48  
L BR93-68-3B2-48
- 13 Cover, Trunk Lid¶ R BR93-68-8J0-48  
L BR93-68-8K0-48
- ¶Blue listed, Order by Application  
19 Red; 32 Gray/Taupe; 48 Blue; 65 Off Black

## INTERIOR TRIM SEDAN




- 1 Trim, Pillar Gray R B455-68-250D-06  
L B455-68-260D-06  
Gray/Taupe R B455-68-250D-35  
L B455-68-260D-35
- 2 Trim, Wheelhouse R B455-68-780A  
L B455-68-770A
- 3 Trim, Trunk Side R BR70-68-851-09  
L BR70-68-871-09
- Trim Assy, Rear Package¶ USA w/High Mount Stop Lamp BR70-68-3A0E-48  
w/o High Mount Stop Lamp BR72-68-3A0D-48  
Canada N.A.
- ¶Blue listed, Order by Application  
19 Red; 32 Gray/Taupe; 48 Blue; 60 Dark Gray
- Grille, Speaker (a) Blue R/L BR72-68-3S0A-48  
Gray/Taupe R/L BR72-68-3S0A-32  
Off Black R/L BR72-68-3S0A-60
- Grille, Extractor¶ (a) R B455-68-3A3-48  
L B455-68-3A4-48
- ¶Blue listed, Order by Application  
19 Red; 32 Gray/Taupe; 48 Blue; 60 Dark Gray  
(a) Included w/Rear Package Trim Assy


# MAZDA 323/PROTEGE 1990-94

Speaker, Radio (b) R/L 0000-81-090A-01  
(b) Order by Application

## QUARTER GLASS




- 1 Glass, Quarter  
Mazda Clear R B467-72-511  
L B467-73-511  
Blue Tint R B469-72-511  
L B469-73-511
- 2 W/Strip, Glass R B467-72-761B  
L B467-73-761B
- 3 Latch, Glass R/L D001-72-310A
- 4 Hinge, Glass Upper R/L B499-72-210B
- 5 Hinge, Glass Lower R/L B499-73-210B
- 6 Moulding, Pillar R B467-50-F10  
L B467-50-F20




- 2 Bracket, Spoiler Side R/L N.A.
  - 3 Bracket, Spoiler Center N.A.
  - 4 Protector, Spoiler Side R/L N.A.
  - 5 Protector, Spoiler Center N.A.
  - 6 Fastener, Spoiler Side R/L N.A.
- †Harbor Blue listed, Order by Application  
DV Blue; DX Honey Blue; FZ Herbie Green;  
PZ Brilliant Black; SQ Blaze Red; SS Coral Red;  
UF Clear White; 1H Steel Gray MC;  
IS Niagara Silver MC; 3L Silver Stone M;  
5D Harbor Blue M; 6L Gracful Red MC;  
6N Current Blue MC; 6S Excess Green MC
- †Included w/Rear Spoiler Assy

## LUGGAGE LID




- 1 Lid, Luggage w/Spoiler BR70-52-610J  
w/o Spoiler BR70-52-610J
- Panel, Finish-See License Lamp Section
- 2 Rubber, Cushion R/L H001-56-801
- Nameplate "Mazda" BR70-51-710  
"Protege" USA BR72-51-720A  
Canada N.A.  
"S" TA01-51-761
- 3 Latch BR70-56-820
- 4 Striker, Latch GJ21-56-840C
- 5 Protector, Latch B455-56-823A
- 6 Cylinder & Key To 8-1-92 BR70-76-230D  
From 8-1-92 BB4E-76-230B  
Fastener, Key Cylinder GJ21-56-902A
- 7 Cable Assy, Release BR71-56-850B
- 8 Cable, Trunk Lid† B456-56-870B
- 9 Cable, Fuel Lid† BR71-56-880
- †Included w/Release Cable Assy
- 10 Hinge R B455-52-710A  
L B455-52-720A
- 11 Cushion, Hinge R/L B455-56-802A
- 12 Bar, Torsion w/Rear Spoiler R B456-52-791B  
L B456-52-792A  
w/o Rear Spoiler R B456-52-791B  
L B456-52-792A
- 13 Protector, Torsion Bar B130-56-805A
- 14 Weatherstrip, Lid B455-56-951B

## REAR SPOILER CANADA 1992-95



- 1 Spoiler Assy, Rear N.A.
  - 2 Support, Center N.A.
  - 3 Bracket, Spoiler (a) Center N.A.
  - †Bluish Green listed, Order by Application  
DV Bay Blue; E9 Deep Purple; J4 Passion Rose;  
PZ Brilliant Black; SQ Blaze Red; UF Clear White;  
Z1 Bluish Green M; 4Z Silent Silver; 5S Neat Green  
6C Mighty Gray; 6M Elegant Beige; 6V Raspberry  
Metallic; 6W Laguna Blue M; 6Y Sea Mist M
  - 4 Stay, Spoiler (a) R/L N.A.
  - 5 Protector, Spoiler (a) R/L N.A.
  - 6 Gasket, Spoiler (a) N.A.
  - 7 Lamp, High Mount Stop (a) N.A.
- (a) Included w/Rear Spoiler Assy


## LIFTGATE




- 1 Spoiler Assy, Rear† N.A.

†Illustration Located in Next Column

- 1 Shell, Gate w/Spoiler BS22-62-020M  
w/o Spoiler  
w/Rear Wiper BR94-62-020K  
w/o Rear Wiper BR93-62-020K
- Nameplate "Mazda" Light Gold B455-51-711A-71  
Light Gray B455-51-711A-85  
Dark Gray B455-51-711A-86
- "Mazda 323" Light Gold BR93-51-721-71  
Light Gray BR93-51-721-85  
Dark Gray BR93-51-721-86  
"S" G263-51-761
- 2 Panel Assy, Finish Outer 90-91 BR93-50-850A  
92-95 BB5A-50-850A  
90-91 BR93-50-852A
- 3 Lens† 92-95 B596-50-852  
90-91 B467-50-853  
92-95 B596-50-853
- 4 Protector† B467-50-855
- 5 Gasket† †Included w/Outer Finish Panel Assy
- 6 Panel, Inside Trim (a) B467-68-960A-48  
(a) Blue listed, Order by Application  
19 Red; 32 Gray Taupe; 48 Blue; 65 Off Black
- 7 Bracket, Trim Panel B467-68-928A
- 8 Wedge, Liftgate R/L B467-62-681
- 9 Latch, Gate B468-62-310A
- 10 Striker, Latch B467-62-361
- 11 Cable Assy, Release BR94-56-850
- 12 Cable, Trunk Lid† BR94-56-870
- 13 Cable, Fuel Lid† BR94-56-880
- †Included w/Release Cable Assy
- Cylinder & Key BR95-76-260A
- 14 Hinge Assy, Liftgate R/L D001-62-210C
- 15 Gasket, Hinge† R/L B001-62-212
- †Included w/Liftgate Hinge Assy
- 16 Stay, Liftgate R 8AB4-62-620  
L 8AB4-63-620
- 17 Weatherstrip B467-62-761



- 18 Glass, Liftgate Mazda Clear B468-63-930  
w/Rear Defroster B467-63-931  
w/o Rear Defroster B469-63-930  
Blue Tint R/L B455-50-891A
  - 19 Spacer, Glass R/L B456-50-899A
  - 20 Dam, Glass B456-50-899A
  - 21 Mldg, Reveal Upper 8AB3-50-611
  - 22 Mldg, Reveal Lower 8AB1-50-614
  - 23 Moulding Assy, Side R/L 8AB2-50-612-3
  - 24 Joint, Mldg Upper† R/L B467-50-615-6
  - 25 Joint, Mldg Lower† R/L B467-50-617-8
- †Included w/Side Moulding Assy




- 26 Blade Assy, Wiper B467-67-330

# MAZDA 323/PROTEGE 1990-94

## LIFTGATE Cont'd

- Insert, Wiper]
  - To 8-1-94 B499-67-331
  - From 8-1-94 B467-67-331
- 27 Arm, Wiper B467-67-421
- 28 Cover, Arm B093-76-641
- 29 Motor Assy, Wiper B467-67-450A
- 30 Bushing, Inner]
  - B467-67-402
- 31 Bushing, Outer B467-67-407
- 32 Cap, Seal B093-67-366A
- 33 Clip, Hose H001-67-057
- 34 Clip, Pipe (2) B499-67-519
- 35 Joint, Hose DB05-67-502
- 36 Protector, Hose LA05-67-506
- 37 Nozzle, Washer B467-67-510
- 38 Tank Assy, Washer B467-67-480C
- 39 Tank, Washer] B467-67-481C
- 40 Cap, Tank] UB39-51-815
- 41 Pump, Washer]
  - 8532-76-672
- 42 Valve, Washer Tank
  - To 2-1-94 B467-67-492C
  - From 2-1-94 B01A-56-054


## REAR SPOILER 1992-95



035-02484

- 1 Spoiler Assy, Rear]
    - To 11-3-93 B603-51-9N0A-Z1
    - From 11-3-93 B603-51-9N0B-Z1
  - 2 Clip, Spoiler Outer (a) R/L B471-51-9N3
  - 3 Clip, Spoiler Center (a) B467-51-9N2
  - 4 Protector, Spoiler Otr (a)
    - Right B603-51-9N5A
    - Left B603-51-9N6A
  - 5 Protector, Center (a) B603-51-9N4
  - 6 Lamp, High Mount Stop (a)
    - To 8-1-94 B603-51-580C
    - From 8-1-94 B603-51-580D
  - 7 Protector, Lamp (a) R/L B603-51-582
- (a) Included w/Rear Spoiler Assy

## REAR SUSPENSION FWD




035-01972

- 1 Rotor, Brake R/L BB4C-26-251C
- 2 Drum, Brake 90-91 R/L BR70-26-251
- 3 Hub Assy, Wheel 92-95 R/L D102-26-251
- 4 Bolt, Hub] R/L B455-26-15XA
- 5 Caliper, Brake R/L B01Y-33-062
- 6 Plate, Backing
  - Drum Brakes 90-91 R BR71-26-280
  - L BR71-26-290


- 7 Shield, Splash
  - Disc Brakes 92-95 R B596-26-280B
  - L BC1D-26-290A
- 90-91 R/L BR74-26-261A
- 92-95 R/L B613-26-261A

- Hose, Brake
  - Drum Brakes R/L B455-43-810C
  - Disc Brakes R/L B461-43-980C
- 8 Spindle, Hub
  - Drum Brakes R B455-26-111D
  - L B455-26-115D
  - Disc Brakes R B461-26-111B
  - L B461-26-115B



035-01973


- 9 Strut Assy
    - 1.6L Eng R B455-28-700
    - L B455-28-900
  - 1.8L Eng USA Std Duty
    - R BR70-28-700A-9U
    - L BR70-28-900A-9U
  - Hvy Duty
    - R B625-28-700A
    - L B625-28-900A
  - Canada R/L N.A.
  - 10 Bolt, Strut (2/Side) R/L 9YA0-21-231C
  - 11 Spring, Coil] R/L BR70-28-011
- Order by Application
- 12 Seat, Rubber R/L B455-28-0A3
  - 13 Stopper, Bumper R/L B455-28-111A
  - 14 Seat, Spring R/L B455-28-340A
  - 15 Insulator, Mounting R/L B595-28-390A
  - 16 Bushing R/L B455-28-343A
  - 17 Cap, Mount R/L B455-28-019
  - 18 Link, Lateral Front R/L BR70-28-620
  - L BR70-28-630
  - R/L BR70-28-600
  - 19 Link, Lateral Rear Bolt, Lateral Link
    - Front R/L B528-28-112A
    - Rear R/L B455-28-113
    - R/L BR70-28-200B
  - 20 Link, Trailing Bolt, Trailing Link
    - Front R/L B455-28-114A
    - Rear R/L B455-28-116



035-01974


- 25 Bar Assy, Stabilizer
    - 1990-91 1.6L Eng B457-28-10X
    - 1.8L Eng
    - Rear Drum Brakes B457-28-10X
    - Rear Disc Brakes B461-28-10X
  - 1992-95 Std Duty B455-28-10X
  - Hvy Duty B462-28-10X
  - Bolt, Stabilizer] R/L G030-28-157
  - Spacer, Stabilizer] 90-91 R/L G030-28-158
  - 92-95 R/L B455-28-157
- Included w/Stabilizer Bar Assy
- 26 Bushing, Bar
    - Rear Drum Brakes R/L BW0A-28-156A
    - Rear Disc Brakes R/L B461-28-156A
  - 27 Bracket, Bar 90-91 R/L B461-34-155A
  - 92-95 R/L E016-28-15YB
  - 28 Crossmember Assy, Suspension 90-91 B455-28-400D
  - 92-95 E016-28-400A
  - 29 Stopper, Rubber] R/L B455-28-809
  - 30 Protector, Crossmember] R/L B455-28-8A2A
- Included w/Suspension Crossmember Assy

## AWD




035-01311

- 1 Rotor, Brake R/L BB4C-26-251C
- 2 Hub Assy, Wheel R/L B01A-33-060A
- 3 Bolt, Hub] R/L B01Y-33-062
- 4 Shield, Splash R/L B530-26-261A
- 5 Caliper, Brake R BRY6-26-98ZR
- L BRY6-26-99ZR
- 6 Knuckle R B531-26-110B
- L B531-26-120C



035-01312

- 7 Strut R B530-28-700
  - L B530-28-900
  - 8 Bolt, Strut (2/Side) R/L 9YA0-21-231C
  - 9 Spring, Coil] R/L BA1C-28-011
- Order by Application
- 10 Seat, Rubber R/L B455-28-0A3
  - 11 Stopper, Bumper R/L B455-28-111A
  - 12 Seat, Spring R/L B455-28-340A
  - 13 Insulator, Mounting R/L B595-28-390A
  - 14 Bushing R/L B455-28-343A
  - 15 Cap, Mount R/L B455-28-019
  - Link, Lateral
    - Front R B528-28-620
    - L B528-28-630
    - R/L B528-28-600A
  - 16 Bolt, Lateral Link
    - Front R/L B528-28-112A
    - Rear R/L B455-28-113
  - 17 Link, Trailing R BR70-28-200B
  - L BR70-28-250
  - Bolt, Trailing Link
    - Front R/L B455-28-114A
    - Rear R/L B455-28-116




035-01313

- 23 Bar Assy, Stabilizer Bolt, Stabilizer] B528-28-10X
- R/L G030-28-157

# MAZDA 323/PROTEGE 1990-94


Spacer, Stabilizer	R/L G030-28-158
*Included w/Stabilizer Bar Assy	
24 Bushing, Bar	R/L B459-34-156A
25 Bracket, Bar	R/L E016-28-15YB
26 Crossmember Assy, Suspension	BA1C-28-400F
27 Stopper, Rubber	R/L B455-28-809
28 Protector, Crossmember	R/L B455-28-8A2A
*Included w/Suspension Crossmember Assy	

## REAR DRIVE AXLE



1 Shaft Assy, Axle	R F058-25-500
	L F058-25-600
2 Joint Set, Outer	R F058-22-510
	L F058-22-610A
3 Joint Set, Inner	R/L F057-22-520
4 Boot Kit, Outer (a)	R/L BS20-V9-050-9U
(a) Included w/Outer Joint Set	
5 Boot Kit, Inner (b)	R/L G071-22-550
*Included w/Axle Shaft Assy	
(b) Included w/Inner Joint Set	

## FUEL TANK




1 Cap Assy, Filler	
1990-91	
FWD	BF67-42-250
AWD	UE54-42-250
1992-95	GN60-42-250
2 Gasket, Cap	BF67-42-252
*Included w/Filler Cap Assy	
3 Cover, Lever	
To 7-1-94	B455-42-242A
From 7-1-94	B01W-42-240A
4 Gasket, Dust Cover	B455-42-244
5 Pipe, Filler	
FWD	
Hatchback	BR93-42-210E
Sedan	BR70-42-210E
AWD	BA1C-42-210A
6 Protector, Filler Pipe	
FWD	
Hatchback	B467-42-291A
Sedan	BR70-42-298C
AWD	B528-42-291
7 Hose, Filler	
FWD	
Hatchback	B467-42-241
Sedan	B455-42-241
AWD	B528-42-241
8 Tank, Fuel	
FWD	
Hatchback	BR93-42-110B
Sedan	BR70-42-110B
AWD	B698-42-110B
9 Band, Fuel Tank	
FWD	
Hatchback	R B467-42-710F
	L BR93-42-720B
Sedan	R B455-42-710E
	L BR70-42-720B
AWD	R B528-42-710B
	L B528-42-720A
10 Insulator, Fuel Tank	B455-42-751A
11 Valve, Check	BR70-42-910A
12 Gauge, Fuel Tank	
FWD	
Hatchback	
w/Warning Switch	B475-60-960A
w/o Warning Switch	BR93-60-960
Sedan	

w/Warning Switch	BS42-60-960
w/o Warning Switch	B617-60-960
AWD	R B530-60-960B
	L B528-60-970A
13 Pump Assy, Fuel	
Electric	
FWD	BP02-13-35ZD
AWD	BP47-13-35ZC
Pump, Fuel Sub (a)	B6DA-13-350
Filter, Fuel Pump (a)	KL22-13-ZE1
*Order by Application	
(a) Included w/Fuel Pump Assy	


## REAR BODY

### SHEET METAL HATCHBACK




1 Panel Assy, Rear Body	B467-70-750A
2 Panel, Rear Body	B467-70-751A
3 Bracket, Lamp	R B467-70-75X
	L B467-71-75X
*Included w/Rear Body Panel Assy	
4 Pillar, Rear Outer	R B467-70-440
	L B467-71-440

### SHEET METAL SEDAN



Panel, Rear End Upper	
*See Rocker/Pillars/Floor Section	
1 Panel, Rear End	B455-70-750A
2 Extension, Rear End	R B455-70-405
	L B455-71-405
3 Bracket, Lamp	R B455-70-490A
	L B455-71-490A
4 Plate, Corner	R B455-70-451
	L B455-71-451


### INTERIOR TRIM HATCHBACK



1 Trim Assy, Rear End	BR93-68-89XC-48
2 Cover, Jack (a)	B467-68-8S0A-48
3 Cover, End Trim (a)	B467-68-893-48
*Blue listed, Order by Application	
19 Red; 32 Gray Taupe; 48 Blue; 65 Off Black	
(a) Included w/Rear End Trim Assy	


### INTERIOR TRIM SEDAN

Illustration Located in Next Column



1 Trim, Rear End	B455-68-891B-09
------------------	-----------------


### FLOOR



1 Panel, Rear End Upper	
Hatchback	B467-53-940D
Sedan	B4Y5-53-940C
2 Pan, Rear Floor	
Hatchback	BR93-53-730C
Sedan	B455-53-730B
3 Panel, Floor Side	
FWD	
Hatchback	R B467-53-740F
	L B467-54-741C
Sedan	R B455-53-740J
	L B455-54-741A
AWD	R B529-53-740E
	L B529-54-741C
4 Crossmember, Center	
Hatchback	B467-53-930D
Sedan	
FWD	B455-53-930C
AWD	B528-53-900A
5 Pan, Center Floor	
FWD	
Hatchback	BR93-53-720D
Sedan	BR70-53-720E
AWD	BA1C-53-720
6 Reinf, Center Floor	R B455-53-715A
	L B455-54-715A
7 Crossmember, Front	
FWD	B455-53-900F
AWD	B528-53-900A
8 Unirail, Rear	
FWD	
Hatchback	R BR93-53-810H
	L BR93-54-810H
Sedan	R BR70-53-810K
	L BR70-54-810J
AWD	R BA1C-53-810D
	L BA1C-54-810F

## REAR LAMPS

### COMBINATION LAMP HATCHBACK 1990-91



1 Lamp Assy	R 8FB2-51-150
	L 8FB2-51-160
2 Lens & Housing Assy	R BR93-51-170
	L BR93-51-180



# MAZDA 323/PROTEGE 1990-94


## REAR LAMPS Cont'd

### COMBINATION LAMP

#### HATCHBACK 1990-91 Cont'd


- 3 Lens & Body<sup>¶</sup> (a) R B467-51-151  
L B467-51-161
  - 4 Gasket<sup>¶</sup> (a) R B467-51-158  
L B467-51-168
  - (a) Included w/Lens & Housing Assy
  - 5 Socket & Wire<sup>¶</sup> R/L B467-51-155
  - 6 Bulb<sup>¶</sup>  
Signal/Stop/Tail R/L 0000-11-1156  
Back-Up R/L 0000-11-0921
  - 7 Bracket, Lamp<sup>¶</sup> R/L B467-51-172
- <sup>¶</sup>Included w/Lamp Assy

### COMBINATION LAMP HATCHBACK 1992-95



- 1 Lamp Assy R 8FBJ-51-150  
L 8FBJ-51-160
  - 2 Lens & Body Assy<sup>¶</sup> R BB7A-51-170  
L BB7A-51-180
  - 3 Lens<sup>¶</sup> (a) R B596-51-151  
L B596-51-161
  - 4 Gasket<sup>¶</sup> (a) R B467-51-158  
L B467-51-168
  - (a) Included w/Lens & Body Assy
  - 5 Socket & Wire<sup>¶</sup> R/L B467-51-155
  - 6 Bulb<sup>¶</sup>  
Signal/Stop/Tail R/L 0000-11-1157  
Back-Up R/L 0000-11-0921
  - 7 Bracket, Lamp<sup>¶</sup> R/L B467-51-172
- <sup>¶</sup>Included w/Lamp Assy

### COMBINATION LAMP SEDAN 1990-91




- 1 Lamp Assy R 8FB1-51-150  
L 8FB1-51-160
  - 2 Lens<sup>¶</sup> R BR70-51-170A  
L BR70-51-180A
  - 3 Gasket<sup>¶</sup> R/L B455-51-158
  - 4 Socket<sup>¶</sup> R B455-51-155  
L B455-51-165
  - 5 Bulb<sup>¶</sup>  
Signal/Stop/Tail R/L 0000-11-1156  
Back-Up R/L 0000-11-0921
  - 6 Moulding, Lamp<sup>¶</sup> R B455-51-159  
L B455-51-169
- <sup>¶</sup>Included w/Lamp Assy

### COMBINATION LAMP SEDAN 1992-95


Illustration Located in Next Column

- 1 Lamp Assy R 8FBK-51-150




- 2 Socket & Wire<sup>¶</sup> L 8BB1-51-560  
R/L BR70-51-554
  - 3 Bulb<sup>¶</sup> R/L 0000-11-0194
- <sup>¶</sup>Included w/Lamp Assy

### REFLECTOR LAMP




- 1 Reflector R BR93-51-5B0A  
L BR93-51-5C0A

### HIGH MOUNT STOP LAMP HATCHBACK




- 1 Lamp Assy (a) (b) BR93-51-580A-PZ
  - (a) Located on Liftgate
  - (b) Brilliant Black listed, Order by Application  
DV Bay Blue; DX Honey Blue; E9 Deep Purple;  
FZ Herbie Green; GU Shade Green;  
PZ Brilliant Black; SQ Blaze Red;  
SS Coral Red; UF Clear White;  
Z1 Bluish Green M; 1H Steel Gray MC;  
1S Niagara Silver MC; 3L Silver Stone M;  
4R Passion Yellow Mica; 4Z Silent Silver;  
5D Harbor Blue M; 5L Whisper Green;  
5S Neat Green; 6C Mighty Gray;  
6L Graceful Red; 6M Elegant Beige;  
6N Current Blue MC; 6S Exceed Green M;  
6V Raspberry Metallic; 6W Laguna Blue M
  - 2 Gasket<sup>¶</sup> BR93-51-582
  - 3 Socket & Wire<sup>¶</sup> BR93-51-584
  - 4 Bulb<sup>¶</sup> 0000-11-0921
  - 5 Cap, Lamp<sup>¶</sup> (a) R BR93-51-586A-PZ  
L BR93-51-596A-PZ
- <sup>¶</sup>Included w/Lamp Assy
- (a) Brilliant Black listed, Order by Application  
DV Bay Blue; DX Honey Blue; E9 Deep Purple;  
FZ Herbie Green; GU Shade Green;  
PZ Brilliant Black; SQ Blaze Red;  
SS Coral Red; UF Clear White;  
Z1 Bluish Green M; 1H Steel Gray MC;  
1S Niagara Silver MC; 3L Silver Stone M;  
4R Passion Yellow Mica; 4Z Silent Silver;  
5D Harbor Blue M; 5L Whisper Green;  
5S Neat Green; 6C Mighty Gray;  
6L Graceful Red; 6M Elegant Beige;  
6N Current Blue MC; 6S Exceed Green M;  
6V Raspberry Metallic; 6W Laguna Blue M

### LICENSE LAMP HATCHBACK




- 1 Lamp Assy 8BB8-51-270
  - 2 Lens<sup>¶</sup> R/L G225-51-274B
  - 3 Gasket<sup>¶</sup> R/L G225-51-273
  - 4 Housing<sup>¶</sup> BR93-51-271
  - 5 Bulb<sup>¶</sup> R/L 0000-11-0168
  - 6 Bracket, Lamp<sup>¶</sup> R/L BR93-51-261
- <sup>¶</sup>Included w/Lamp Assy

### LICENSE LAMP SEDAN




- 1 Panel Assy, Finish Outer 90-91 BR70-50-850  
92-95 BB4W-50-850A
  - 2 Lens<sup>¶</sup>-Serviced w/Outer Finish Panel Assy
  - 3 Cover, Lamp<sup>¶</sup> 90-91 R BR70-51-283  
L BR70-51-293  
92-95 R B623-51-283  
L B623-51-293
  - 4 Gasket<sup>¶</sup> R/L BR70-50-855
  - 5 Gasket, Side<sup>¶</sup> R/L BR70-50-865
  - 6 Socket<sup>¶</sup> R/L BR70-51-272
  - 7 Bulb<sup>¶</sup> R/L BR70-51-686
  - 8 Protector<sup>¶</sup> 90-91 B455-50-853A  
92-95 B617-50-853
- <sup>¶</sup>Included w/Outer Finish Panel Assy

### SIDE MARKER LAMP



- 1 Lamp Assy R 8BB1-51-550

### HIGH MOUNT STOP LAMP SEDAN W/SPOILER



- 1 Lamp Assy (a) BR74-51-580
  - 1990-91
  - 1992-95-See Luggage Lid Section
  - (a) Located on Spoiler
  - 2 Lens<sup>¶</sup> GJ22-51-593
  - 3 Socket & Wire<sup>¶</sup> BR74-51-584
  - 4 Bulb<sup>¶</sup> 0000-11-0921
- <sup>¶</sup>Included w/Lamp Assy

### HIGH MOUNT STOP LAMP SEDAN W/O SPOILER

Illustration Located in Next Column

- 1 Lamp Assy<sup>¶</sup> (a) BR70-51-580-48
- (a) Located on Package Tray
- 2 Lens & Body<sup>¶</sup> (b) GE61-51-593-48
- <sup>¶</sup>Blue listed, Order by Application  
19 Red; 32 Gray Taupe; 48 Blue; 65 Off Black
- 3 Socket & Wire (b) 0000-11-0921
- 4 Bulb (b) 0000-11-0921