



MAZDA 323

J M Z B **0 0 1 2 3 4 5 6**

Make

All Mazdas produced in Japan for Europe are identified by JMZ chassis number. (With the exception of Grey Imports.)

Model

B = 323

Model Code

D = BD Series (1980 -1985)
F = BF Series (1985 - 1989)
G = BG Series (1989 - 1994)
V = BV Series (1981 -1986)
W = BW Series (1986-1995)
A = BA Series (1994 -)
J = BJ Series (05/98 -)

Drive Type

1 = 2WD (BD/BF/BG/BW/BA/BJ Series)
2 = 2WD (BV/BG/BF Series)
8 = 4WD (BF/BG Series)

Body Style

1 = 2 door Estate (BV/BJ Series)
2 = 4 door H/Back (BD/BF/BG/BA Series) or
4 door Estate (BV/BW Series)
3 = 3 door H/Back (BD/BF/BG/BA/BJ Series)
4 = 5 door H/Back (BD/BF/BG/BA/BJ Series)

Serial Number

Transmission

1 = MTM (4 speed)
2 = MTM (5 speed)
3 = ATM (3 speed)
4 = ATM (4 speed)
5 = ATM (4 speed)

Engine

1= 1.1 **E1** (BD Series) or 1.1 **E1** (BF Series)
2= 1.3 **E3** (BG/BD Series)
3= 1.1 **E1** (BF Series) or 1.3 **E3** (BD Series)
or 1.3 **B3** (BA Series) or 1.5 **D5** (BV Series)
or 1.3 Petrol (BJ Series)
4= 1.5 **E5** (BD Series) or 1.6 **B6** (BG Series)
5= 1.3 **E3** (BF Series) or 1.5 **Z5** (BA Series)
or 1.5 GT **E5** (BD Series)
6= 1.5 **B5** (BF Series) or 1.5 **E5** (BW Series)
7= 1.6 inj. **B6** (BF Series) or 1.6 **B6** (BW Series)
or 1.8 inj. **B8** (BG Series)
8= 1.6 inj. **B6** (BF Series)
A= 1.3 **B3** (BF Series) or 1.8 inj.16v (BG Series)
B= 1.3 **B3** (BF/BG Series)
C= 1.5 **B5** (BF/BW Series)
or 1.3 inj. **B3** (BG Series)
D= 1.6 **B6** (BG Series)
E= 1.6 inj. **B6** (BG Series)
F= 2.0 inj. V6 **KF** (BA Series) or 1.8 inj. B8 (BG Series)
or 2.0 Diesel (BJ Series)
G=1.6 Turbo **B6T** (BF Series) or 1.8 inj. (BG Series)
I = 1.6 Turbo **B6T** (BG Series)
J=1.5 **B5** + CAT. (BW Series) or 1.8 inj. (BG Series)
L= 1.5 Petrol (BJ Series)
M= 1.6 Petrol (BJ Series)
P= 1.8 inj. **B8** (BA Series) or 1.8 (BJ Series)
R= 2.0 Diesel Turbo (BJ Series)

MAZDA 626

J M Z G **0 0 1 2 3 4 5 6**

Make

All Mazdas produced in Japan for Europe are identified by JMZ chassis number. (With the exception of Grey Imports.)

Model

G = 626

Model Code

C = GC Series (1983-1987)
D = GD Series (1987-1993)
E = GE Series (1992-)
V = GV Series (1988-1994)
F = GF Series (1997-)
W = GW Series (1998 -)

Drive Type

1 = 2WD/2WS (GC/GD/GE/GV Series)
7 = 2WD/4WS (GD Series only)
8 = 4WD/2WS (GV Series only)

Body Style

2 = Saloon (GC/GD/GE Series only) or
Estate (GV/GW Series only)
4 = Hatchback (GC/GD/GE/GF Series only)
6 = Coupe (GC/GD Series only)

Serial Number

Transmission

1 = 4 spd MTM (GC Series)
2 = 5 spd MTM
3 = ATM (GC/GV Series)
4 = ATM (GD/GV Series)
5 = ATM (GD/GE Series)

Engine

1 = 1.6 Carb 8v (**GC** Series)
or 1.8 Carb 8v (**GD/GV** Series)
2 = 2.0 Carb 8v (**GC** Series)
3 = 2.0 Carb 12v (**GC/GD/GV** Series)
4 = 2.0 Inj 16v (**GC** Series)
or 2.0 Super Charged Diesel (**GE** Series)
5 = 2.0 Carb 8v (**GC** Series)
or 2.0 Inj. 16v DOHC (**GD/GV** Series)
6 = 2.0 Inj 8v (**GC** Series)
or 2.0 Carb 12v (**GV** Series)
9 = 1.8 Carb (**GD** Series)
A = 1.8 Inj 16v DOHC (**GE** Series)
C = 2.0 Carb 12v (**GV** Series)
D = 2.0 Carb 12v (**GD/GV** Series)
or 2.0 Inj 16v DOHC
E = 2.0 Inj 16v DOHC (**GD/GV** Series)
F = 2.5 Inj V6 (**GE** Series)
or 2.0 Inj (**GF/GW** Series)
H = 2.2 Inj 12v (**GD** Series)
J = 2.0 Inj 16v DOHC (**GE** Series)
P = 1.8 Inj 16v DOHC (**GF/GW** Series)
R = 2.0 Diesel (**GF/GW** Series)
S = 2.0 Inj (**GF/GW** Series)